

Kawasaki

Assembly Instructions

Description:	305mm Windshield Kit	Model:	Vulcan 1700 Vaquero
Part Number:	K99994-0175A	Assembly Time:	15 min.

Before you begin installation, read through the installation instructions and check to be sure all parts are present.

If you are in doubt as to any part of the installation, please ask your authorized Kawasaki dealer to complete the installation. Please note that Kawasaki cannot assume any responsibility for damage resulting from incorrect installation.

Parts List				Tools Required:
Seq.	Part Number	Description	Qty.	Tool Description
1.	K99994-0175	Windshield	1	4mm Hex Wrench
2.	14091-0949	Chrome Cover	1	
3.	92161-0656	Damper	1	
4.	92154-0206	60 x 30mm Socket Bolt	5	
5.	92200-3775	Flat Washer	5	

Installation Instructions

Windshield Installation Preparation

Parts Removal

- Remove the stock wind deflector.

NOTE:

O Stock hardware will not be re-used.

Install Windshield

- Install windshield using provided chrome cover, rubber damper (under cover) washers and screws.

NOTE:

O Tighten screws firmly, do not overtighten.



Maintenance

- To clean, pre-rinse screen with water to remove grit and soften dirt. Use mild soap, lots of warm water, and a clean soft cloth or sponge. Rinse well to remove all soap residue. Dry with a soft cloth. Washing may be followed by Kawasaki Plastic and Glass cleaner (K61080-002C), or other similar product.

Please check / adjust all screws in regular intervals.