

2009 Vulcan® 1700 Voyager®

PARTS LIST

Saddlebags(Side Bag Bracket)

| ITEM NAME | PART NUMBER | QUANTITY |
|---|-------------|----------|
| BOLT-FLANGED,8X14 (Ref # 130) | 130BA0814 | 2 |
| BOLT-FLANGED,8X35 (Ref # 130A) | 130BA0835 | 2 |
| BOLT-FLANGED,8X40 (Ref # 130B) | 130BA0840 | 4 |
| BOLT-FLANGED,8X20 (Ref # 130C) | 130CA0820 | 4 |
| COVER,STAY,LWR,LH (Ref # 14091) | 14091-0950 | 1 |
| COVER,STAY,LWR,RH (Ref # 14091A) | 14091-0951 | 1 |
| COVER,STRUT,LH (Ref # 14091B) | 14091-0957 | 1 |
| COVER,STRUT,RH (Ref # 14091C) | 14091-0958 | 1 |
| COVER,STAY,UPP,LH (Ref # 14091D) | 14091-1661 | 1 |
| COVER,STAY,UPP,RH (Ref # 14091E) | 14091-1662 | 1 |
| STAY,PANNIER (Ref # 35063) | 35063-0537 | 1 |
| STAY-COMP,PANNIER,LH (Ref # 39137) | 39137-0048 | 1 |
| STAY-COMP,PANNIER,RH (Ref # 39137A) | 39137-0049 | 1 |
| SCREW,6X10,WHITE (Ref # 92009) | 92009-1286 | 2 |
| SCREW,5X16,WHITE (Ref # 92009A) | 92009-1464 | 14 |
| NUT,WELL,5MM (Ref # 92015) | 92015-1757 | 10 |
| BOLT,SOCKET,5X16 (Ref # 92154) | 92154-0287 | 8 |
| WASHER,NATURAL,5.3X11.5X1.0 (Ref # 92200) | 92200-0538 | 22 |