

## Cowling

**Let the Good Times Roll®**



# 2009 Ninja® 250R

## PARTS LIST

### Cowling

| ITEM NAME                                 | PART NUMBER    | QUANTITY |
|-------------------------------------------|----------------|----------|
| BOLT-FLANGED,8X30 (Ref # 130)             | 130BB0830      | 2        |
| WASHER-PLAIN,8.5X18X1.6 (Ref # 411)       | 411AB0800      | 4        |
| BRACKET (Ref # 11054)                     | 11054-1457     | 2        |
| BRACKET,MIRROR,LH (Ref # 11054A)          | 11054-1613     | 1        |
| BRACKET,MIRROR,RH (Ref # 11054B)          | 11054-1614     | 1        |
| COVER,METER (Ref # 14091)                 | 14091-0722     | 1        |
| STAY-COMP,UPP COWLING,BLACK (Ref # 39137) | 39137-0047-18R | 1        |
| WINDSHIELD (Ref # 39154)                  | 39154-0028     | 1        |
| COWLING,UPP,S.RED (Ref # 55028)           | 55028-0153-H1  | 1        |
| COWLING,UPP,M.D.BLACK (Ref # 55028E)      | 55028-0153-15Q | 1        |
| COWLING,UPP,C.T.BLUE (Ref # 55028G)       | 55028-0153-620 | 1        |
| MIRROR-ASSY,LH (Ref # 56001)              | 56001-0098     | 1        |
| MIRROR-ASSY,RH (Ref # 56001A)             | 56001-0099     | 1        |
| NUT,6MM (Ref # 92015)                     | 92015-1094     | 2        |
| NUT,FLANGED,6MM,BLACK (Ref # 92015A)      | 92015-1233     | 4        |
| BOLT,SOCKET,6X14 (Ref # 92151)            | 92151-1654     | 2        |
| BOLT,6X18 (Ref # 92153)                   | 92153-0816     | 4        |
| BOLT,SOCKET,5X16 (Ref # 92154)            | 92154-0182     | 8        |
| BOLT,SOCKET,5X20 (Ref # 92154A)           | 92154-0216     | 2        |
| DAMPER,MIRROR (Ref # 92160)               | 92160-1089     | 4        |
| WASHER,6.5X17X1 (Ref # 92200)             | 92200-0430     | 2        |
| WASHER,NYLON,5.2X12X1 (Ref # 92200A)      | 92200-1011     | 8        |
| NUT,CAP,8MM (Ref # 92210)                 | 92210-0488     | 2        |
| NUT,WELL,5MM (Ref # 92210A)               | 92210-0498     | 10       |