


Cowling Lowers



2018 NINJA® 650 ABS PARTS LIST

Cowling Lowers

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SIDE COWL.,LH (Ref # 11057)	11057-0130	1
BRACKET,LWR COWL.,LH (Ref # 11057A)	11057-0131	1
BRACKET,SIDE COWL.,RH (Ref # 11057B)	11057-0132	1
BRACKET,LWR COWL.,RH (Ref # 11057C)	11057-0133	1
COVER,SIGNAL LAMP (Ref # 14093)	14093-0603	2
COWLING,FRONT NOSE (Ref # 55028)	55028-0593	1
COWLING,SIDE,LH,P.S.GRAY (Ref # 55028B)	55028-0594-36S	1
COWLING,SIDE,LH,C.P.BLUE (Ref # 55028E)	55028-0594-723	1
COWLING,SIDE,RH,P.S.GRAY (Ref # 55028G)	55028-0595-36S	1
COWLING,SIDE,RH,C.P.BLUE (Ref # 55028J)	55028-0595-723	1
COWLING,SIDE,INNER,LH (Ref # 55028K)	55028-0596	1
COWLING,SIDE,INNER,RH (Ref # 55028L)	55028-0597	1
COWLING,LWR,RH,EBONY (Ref # 55028O)	55028-0599-H8	1
COWLING,LWR,FR,LH (Ref # 55028P)	55028-0600	1
COWLING,LWR,FR,RH (Ref # 55028Q)	55028-0601	1
COWLING,SIDE,RR,LH (Ref # 55028R)	55028-0602	1
COWLING,SIDE,RR,RH (Ref # 55028S)	55028-0603	1
COWLING,LWR,LH,EBONY (Ref # 55028V)	55028-0634-H8	1
NUT,WELL,5MM (Ref # 92015)	92015-1757	4
RIVET,HOLE 8MM (Ref # 92039)	92039-0014	1
RIVET (Ref # 92039A)	92039-0709	11
GROMMET (Ref # 92071)	92071-1043	4
COLLAR (Ref # 92152)	92152-1359	2
COLLAR (Ref # 92152A)	92152-1592	2
BOLT,6X18 (Ref # 92153)	92153-0478	2
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0209	8
BOLT,SOCKET,5X20 (Ref # 92154A)	92154-0210	2
BOLT,FLANGED,6X14 (Ref # 92154B)	92154-1426	4
DAMPER (Ref # 92160)	92160-1613	4

2018 NINJA® 650 ABS PARTS LIST

Cowling Lowers

ITEM NAME	PART NUMBER	QUANTITY
DAMPER,8X16X8.6 (Ref # 92161)	92161-0685	2
SCREW,TAPPING,5X10 (Ref # 92172)	92172-0262	8
SCREW,5X12 (Ref # 92172A)	92172-0821	11
WASHER,NYLONE,5.3X11.5X0.5 (Ref # 92200)	92200-0006	4
WASHER,10.4X15.9X0.5 (Ref # 92200A)	92200-0157	2
WASHER,5.5X18X1.6 (Ref # 92200B)	92200-0857	2
NUT (Ref # 92210)	92210-0571	4