

Rear Suspension

Let the Good Times Roll®

This diagram illustrates the assembly of a vehicle suspension component, likely a control arm or steering knuckle. The main body is labeled 33001. Key components and their assembly points are indicated by numbered callouts:

- 92153**: A bolt used to secure the top of the assembly.
- 45014**: A shock absorber or coil spring assembly that fits into the top of the main body.
- 33032** and **92153A**: Two long bolts that pass through the main body and are secured with a nut.
- 92139**: A cylindrical bush or spacer that fits into the main body.
- 92210A** and **36014A**: A bracket and a bolt that attach to the side of the main body.
- 36014**: A large, curved component, possibly a fender or wheel arch trim, that fits around the main body.
- 12053**: A small cylindrical pin or bush.
- 92026**: A small cylindrical pin or bush.
- 92139**: A second cylindrical bush or spacer.
- 92210**: A small cylindrical pin or bush.
- 36014B**: A bracket or support piece that fits under the main body.
- 92172**: A small screw or bolt that secures the large curved component.



2005 KFX50

PARTS LIST

Rear Suspension

ITEM NAME	PART NUMBER	QUANTITY
GUIDE-CHAIN (Ref # 12053)	12053-S013	1
ARM-COMP-SWING,BLACK (Ref # 33001)	33001-S005-503	1
SHAFT-SWING ARM (Ref # 33032)	33032-S002	1
CASE-CHAIN (Ref # 36014)	36014-S002	1
CASE-CHAIN (Ref # 36014A)	36014-S003	1
CASE-CHAIN (Ref # 36014B)	36014-S004	1
SHOCKABSORBER,L.GREEN (Ref # 45014)	45014-S021-535	1
SPACER (Ref # 92026)	92026-S063	1
BUSHING (Ref # 92139)	92139-S015	2
BOLT,10X37 (Ref # 92153)	92153-S033	1
BOLT,REAR SHOCK (Ref # 92153A)	92153-S204	1
SCREW,6X16 (Ref # 92172)	92172-S073	6
NUT (Ref # 92210)	92210-S007	1
NUT (Ref # 92210A)	92210-S030	1