

Swingarm

Diagram illustrating the assembly of a vehicle chassis component, showing various parts and their assembly sequence.

Parts and Assembly Sequence:

- 33001**: Main chassis component.
- 92015B**: Nut.
- Ref. Frame**: Reference frame.
- 33032**: Long bolt.
- 42036**: Tube.
- 92046**: Washer.
- 92049**: Washer.
- 92210**: Pin.
- 55020**: Bracket.
- 92151**: Bolt.
- 33040**: Bracket.
- 33040A**: Bracket.
- 11012**: Pin.
- 92015A**: Nut.
- 92022**: Washer.
- 92015**: Nut.

Assembly Steps:

- Install **92015B** on **Ref. Frame**.
- Install **33032** through **42036** and **92046** into **33001**.
- Install **92049** and **92046** on **33001**.
- Install **92210** on **33001**.
- Install **55020** and **92151** on **33001**.
- Install **33040** on **33001**.
- Install **33040A** on **33001**.
- Install **11012**, **92015A**, **92022**, and **92015** on **33040A**.

2016 Ninja® 300 SE PARTS LIST

Swingarm

ITEM NAME	PART NUMBER	QUANTITY
CAP,CHAIN ADJUSTER,F.S.BLACK (Ref # 11012)	11012-1871-18R	2
ARM-COMP-SWING,F.S.BLACK (Ref # 33001)	33001-0632-18R	1
SHAFT-SWING ARM (Ref # 33032)	33032-1134	1
ADJUSTER-CHAIN,OUTER,F.S.BLACK (Ref # 33040)	33040-0030-18R	2
ADJUSTER-CHAIN,INNER (Ref # 33040A)	33040-1116	2
SLEEVE,16.1X22X213 (Ref # 42036)	42036-1218	1
GUARD,CHAIN (Ref # 55020)	55020-0317	1
NUT,8MM (Ref # 92015)	92015-1364	2
NUT,8MM (Ref # 92015A)	92015-1658	2
NUT,FLANGED,16MM (Ref # 92015B)	92015-1946	1
WASHER,8.5X16X1.2 (Ref # 92022)	92022-1582	2
BEARING-NEEDLE,22X28X20 (Ref # 92046)	92046-0610	2
SEAL-OIL,MHA22 28 5.7F (Ref # 92049)	92049-1254	2
BOLT,SOCKET,6X18 (Ref # 92151)	92151-1149	1
NUT,POP,6MM,L=15 (Ref # 92210)	92210-1397	2