

2009 Brute Force 650 4x4 Hardwoods Green HD

Kawasaki
Let the Good Times Roll®

PARTS LIST

Front Fender(s)

ITEM NAME	PART NUMBER	QUANTITY
COVER,SIDE,RR,LH (Ref # 14091)	14091-1282	1
COVER,SIDE,RR,RH (Ref # 14091A)	14091-1283	1
COVER,SIDE,FR,LH (Ref # 14091B)	14091-1428	1
COVER,SIDE,FR,RH (Ref # 14091C)	14091-1429	1
FENDER-FRONT,C.H.GREEN (Ref # 35004)	35004-0044-826	1
FLAP,FR,LH,F.BLACK (Ref # 35019)	35019-0038-6Z	1
FLAP,FR,RH,F.BLACK (Ref # 35019A)	35019-0039-6Z	1
SHROUD,FR,LWR (Ref # 49125)	49125-0006	1
SHROUD,FR,UPP (Ref # 49125A)	49125-1081	1
SCREW,TAPPING,5X14 (Ref # 92009)	92009-1197	8
SCREW,6X16 (Ref # 92009A)	92009-1621	11
SCREW,6X14 (Ref # 92009B)	92009-1662	8
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	6
NUT,CLAMP,6MM (Ref # 92015A)	92015-1678	2
WASHER,6.5X16X1.0 (Ref # 92022)	92022-1093	6
RIVET (Ref # 92039)	92039-1229	5
SEAL,FR FENDER,LH (Ref # 92093)	92093-0038	1
SEAL,INNER COVER,LH (Ref # 92093A)	92093-0039	1
SEAL,INNER COVER,RH (Ref # 92093B)	92093-0040	1
COLLAR (Ref # 92143)	92143-1087	2
COLLAR,L=60.7 (Ref # 92152)	92152-0026	2
COLLAR,L=76.8 (Ref # 92152A)	92152-0222	2
COLLAR (Ref # 92152B)	92152-0224	6
BOLT,FLANGED,8X75 (Ref # 92153)	92153-0982	2
BOLT,FLANGED,8X95 (Ref # 92153A)	92153-0983	2
DAMPER,L=25.5 (Ref # 92161)	92161-1166	4
SCREW,6X18 (Ref # 92172)	92172-0002	4
SCREW,6X10 (Ref # 92172A)	92172-0005	2
NUT,6MM (Ref # 92210)	92210-1368	9