

## Cowling

Diagram illustrating the assembly of a vehicle front end component, showing various parts and their reference numbers:

- 55027
- 55059/A~C
- 92160
- 55028A
- 92172
- 92210
- 92210
- 92172
- 92210
- 92210
- 92172
- Ref. Headlight(s)
- 130
- 92154
- 130
- 130
- 92154
- 92210
- 92210
- 55059D~F
- 92210
- 55059G~I
- 92172
- 11057
- 55028
- 92154A

Inset diagram showing the assembly of the front end component (55027) with the front end bracket (FNFBN) and the front end bracket (WD).

# 2022 Z900 ABS

## PARTS LIST

### Cowling

| ITEM NAME                                    | PART NUMBER    | QUANTITY |
|----------------------------------------------|----------------|----------|
| BRACKET (Ref # 11057)                        | 11057-2669     | 1        |
| COWLING,LWR (Ref # 55028)                    | 55028-0704     | 1        |
| COWLING,INNER (Ref # 55028A)                 | 55028-0705     | 1        |
| COWLING,UPP,M.M.T.BLUE (Ref # 55059)         | 55059-5156-68M | 1        |
| COWLING,UPP,P.R.WHITE (Ref # 55059A)         | 55059-5156-68N | 1        |
| COWLING,UPP,M.F.S.BLACK (Ref # 55059B)       | 55059-5156-739 | 1        |
| COWLING,UPP,SIDE,LH,M.S.BLACK (Ref # 55059D) | 55059-5157-660 | 1        |
| COWLING,UPP,SIDE,RH,M.S.BLACK (Ref # 55059G) | 55059-5158-660 | 1        |
| BOLT,SOCKET,5X16 (Ref # 92154)               | 92154-0209     | 2        |
| BOLT,SOCKET,5X20 (Ref # 92154A)              | 92154-0829     | 2        |
| DAMPER (Ref # 92160)                         | 92160-1190     | 1        |
| SCREW,TAPPING,5X10 (Ref # 92172)             | 92172-0262     | 5        |
| NUT (Ref # 92210)                            | 92210-0571     | 8        |
| BOLT-FLANGED,5X14 (Ref # 130)                | 130BA0514      | 5        |