


2011 VULCAN® 1700 NOMAD™

PARTS DIAGRAM

Fenders



2011 VULCAN® 1700 NOMAD™

PARTS LIST

Fenders

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,8X25 (Ref # 120)	120CA0825	4
COVER,HARNESS CONNECTOR (Ref # 14091)	14091-1630	1
FENDER-COMP-REAR,EBONY (Ref # 35022)	35022-0066-H8	1
FENDER-COMP-REAR,C.N.BLUE (Ref # 35022E)	35022-0066-27Z	1
FENDER-COMP-FRONT,EBONY/GRAY (Ref # 35040C)	35040-5056-27P	1
FENDER-COMP-FRONT,BLUE/SILVER (Ref # 35040D)	35040-5057-33E	1
BOLT,FLANGED,8X28 (Ref # 92001)	92001-1095	4
GROMMET (Ref # 92071)	92071-1228	1
GROMMET (Ref # 92071A)	92071-1265	1
DAMPER (Ref # 92075)	92075-1067	1
BOLT-FLANGED,6X12 (Ref # 130)	130BA0612	2
BOLT-FLANGED,8X16 (Ref # 130A)	130BA0816	2