

Shock Absorber(s)

Diagram illustrating the assembly of the front and rear shock absorbers, showing the components and their corresponding callout numbers:

- Front Shock Absorber (FR):**
 - 45014: Main shock absorber body.
 - 92210: Top mounting nut.
 - 92092: Top mounting sleeve.
 - 92153: Top mounting bolt.
 - 92093: Lower mounting sleeve.
 - 42036: Lower mounting sleeve.
 - 92139: Lower mounting sleeve.
 - 92093: Lower mounting sleeve.
- Rear Shock Absorber (RR):**
 - 45014A: Main shock absorber body.
 - 92210: Top mounting nut.
 - 92092: Top mounting sleeve.
 - 92153: Top mounting bolt.
 - 92093: Lower mounting sleeve.
 - 42036: Lower mounting sleeve.
 - 92139: Lower mounting sleeve.
 - 92093: Lower mounting sleeve.

2013 BRUTE FORCE® 750 4x4i EPS PARTS LIST

Shock Absorber(s)

ITEM NAME	PART NUMBER	QUANTITY
SLEEVE (Ref # 42036)	42036-0018	4
SHOCKABSORBER,FR,BLACK (Ref # 45014)	45014-0314-17D	2
SHOCKABSORBER,RR,BLACK (Ref # 45014A)	45014-0315-17D	2
BUSHING-RUBBER (Ref # 92092)	92092-0007	4
SEAL (Ref # 92093)	92093-0033	8
BUSHING (Ref # 92139)	92139-0084	4
BOLT,FLANGED,10X50 (Ref # 92153)	92153-1139	8
NUT,LOCK,FLANGED,10MM (Ref # 92210)	92210-0276	8