

Rear Fender(s)

Let the Good Times Roll®



2015 Vulcan 1700 Vaquero ABS

PARTS LIST

Rear Fender(s)

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,8X25 (Ref # 120)	120CA0825	4
BOLT-FLANGED,6X12 (Ref # 130)	130BA0612	2
BOLT-FLANGED,8X16 (Ref # 130A)	130BA0816	2
BRACKET,LH (Ref # 11056)	11056-0390	1
BRACKET,RH (Ref # 11056A)	11056-0391	1
BRACKET (Ref # 11056B)	11056-1087	1
COVER,HARNESS CONNECTOR (Ref # 14091)	14091-1630	1
COVER,M.C.GRAY (Ref # 14092A)	14092-0797-51A	1
COVER,C.L.GREEN (Ref # 14092B)	14092-0797-51P	1
COVER,STRUT,LH,M.C.GRAY (Ref # 14092F)	14092-0800-51A	1
COVER,STRUT,LH,C.L.GREEN (Ref # 14092G)	14092-0800-51P	1
COVER,STRUT,RH,M.C.GRAY (Ref # 14092K)	14092-0801-51A	1
COVER,STRUT,RH,C.L.GREEN (Ref # 14092L)	14092-0801-51P	1
FENDER-COMP-REAR,M.C.GRAY (Ref # 35022A)	35022-0083-51A	1
FENDER-COMP-REAR,C.L.GREEN (Ref # 35022B)	35022-0083-51P	1
TAPE (Ref # 39188)	39188-0016	2
SCREW,TAPPING,5X10 (Ref # 92009)	92009-1332	2
NUT,WELL,5MM (Ref # 92015)	92015-1757	1
WASHER,6.5X16X1.0 (Ref # 92022)	92022-1654	2
GROMMET (Ref # 92071)	92071-1187	4
GROMMET (Ref # 92071A)	92071-1228	1
GROMMET (Ref # 92071B)	92071-1265	1
DAMPER (Ref # 92075)	92075-1067	1
BOLT,SOCKET,6X14 (Ref # 92151)	92151-1654	2
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0209	5
DAMPER (Ref # 92160)	92160-1613	2
WASHER,NYLONE,5.3X11.5X0.5 (Ref # 92200)	92200-0006	4