

Cowling

Let the Good Times Roll®



2008 Ninja® 250R

PARTS LIST

Cowling

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,8X30 (Ref # 130)	130BB0830	2
WASHER-PLAIN,8.5X18X1.6 (Ref # 411)	411AB0800	4
BRACKET (Ref # 11054)	11054-1457	2
BRACKET,MIRROR,LH (Ref # 11054A)	11054-1613	1
BRACKET,MIRROR,RH (Ref # 11054B)	11054-1614	1
COVER,METER (Ref # 14091)	14091-0722	1
STAY-COMP,UPP COWLING,BLACK (Ref # 39137)	39137-0047-18R	1
WINDSHIELD (Ref # 39154)	39154-0028	1
COWLING,UPP,EBONY (Ref # 55028B)	55028-0153-IG	1
COWLING,UPP,P.RED (Ref # 55028D)	55028-0153-15I	1
COWLING,UPP,L.GREEN (Ref # 55028H)	55028-0153-777	1
MIRROR-ASSY,LH (Ref # 56001)	56001-0098	1
MIRROR-ASSY,RH (Ref # 56001A)	56001-0099	1
NUT,6MM (Ref # 92015)	92015-1094	2
NUT,FLANGED,6MM,BLACK (Ref # 92015A)	92015-1233	4
BOLT,SOCKET,6X14 (Ref # 92151)	92151-1654	2
BOLT,6X18 (Ref # 92153)	92153-0816	4
BOLT,SOCKET,5X16 (Ref # 92153A)	92153-1244	8
BOLT,SOCKET,5X20 (Ref # 92154A)	92154-0216	2
DAMPER,MIRROR (Ref # 92160)	92160-1089	4
WASHER,6.5X17X1 (Ref # 92200)	92200-0430	2
WASHER,NYLON,5.2X12X1 (Ref # 92200A)	92200-1011	8
NUT,CAP,8MM (Ref # 92210)	92210-0488	2
NUT,WELL,5MM (Ref # 92210A)	92210-0498	10
COWLING,UPP,C.P.BLUE (Ref # 55028C)	55028-0153-15D	1