

Cowling

Let the Good Times Roll®

F2871

FRONT

92154 92200 92015 39154 55028K 92039 92015 92150 56001A 92154A 92200 56001 92039 92015 55028J 55028/A~F 92172 39156 11055 92172 92154A 92200 11055A Ref. Headlight(s) Ref. Generator Ref. Cowling Lowers

(55028G~I)

WOD	
(55028G)	Ebony
(55028H)	Black
(55028I)	Green

2009 Ninja ZX-6R Monster Energy

PARTS LIST

Cowling

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,INNER COWLING (Ref # 11055)	11055-1278	1
BRACKET,INNER COWLING (Ref # 11055A)	11055-1513	1
WINDSHIELD (Ref # 39154)	39154-0030	1
PAD (Ref # 39156)	39156-0320	2
COWLING,UPP,EBONY (Ref # 55028)	55028-0251-H8	1
COWLING,UPP,CNT,F.S.BLACK (Ref # 55028H)	55028-0290-18T	1
COWLING,INNER,LH (Ref # 55028J)	55028-0296	1
COWLING,INNER,RH (Ref # 55028K)	55028-0297	1
MIRROR-ASSY,LH (Ref # 56001)	56001-0146	1
MIRROR-ASSY,RH (Ref # 56001A)	56001-0147	1
NUT,WELL,5MM (Ref # 92015)	92015-1757	8
RIVET (Ref # 92039)	92039-0068	4
BOLT,SOCKET,6X18 (Ref # 92150)	92150-1553	4
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0026	4
BOLT,SOCKET,5X16 (Ref # 92154A)	92154-0209	4
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0175	9
WASHER,NYLON,5.3X11.5X0.5 (Ref # 92200)	92200-0006	8
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0175	10