

Cowling Lowers(RAF-RBF)

Let the Good Times Roll®



2010 Ninja® ZX™-6R

PARTS LIST

Cowling Lowers(RAF-RBF)

ITEM NAME	PART NUMBER	QUANTITY
PAD,COWLING,SIDE,LH&RH,UPP (Ref # 39156)	39156-0470	2
PAD,COWLING,SIDE,LH,LWR (Ref # 39156A)	39156-0472	1
PAD,COWLING,SIDE,RH,LWR (Ref # 39156B)	39156-0473	1
PAD,COWLING,LWR,LH (Ref # 39156C)	39156-0474	1
PAD,COWLING,LWR,RH (Ref # 39156D)	39156-0475	1
COWLING,CNT,LH (Ref # 55028J)	55028-0254	1
COWLING,CNT,RH (Ref # 55028K)	55028-0255	1
COWLING,LWR,LH,L.GREEN (Ref # 55028O)	55028-0256-777	1
COWLING,LWR,RH,L.GREEN (Ref # 55028S)	55028-0257-777	1
COWLING,LWR,CNT (Ref # 55028T)	55028-0258	1
COWLING,FR,LH (Ref # 55028U)	55028-0260	1
COWLING,FR,RH (Ref # 55028V)	55028-0261	1
COWLING,FR,CNT (Ref # 55028W)	55028-0293	1
COWLING-ASSY.LH,M.S.BLACK (Ref # 55053)	55053-5414-660	1
COWLING-ASSY.RH,M.S.BLACK (Ref # 55053A)	55053-5415-660	1
NUT,WELL,5MM (Ref # 92015)	92015-1757	10
RIVET,HOLE 8MM (Ref # 92039)	92039-0014	1
RIVET (Ref # 92039A)	92039-0068	12
DAMPER (Ref # 92075)	92075-1011	5
BOLT,SOCKET,6MM (Ref # 92153)	92153-0489	6
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0209	8
BOLT,SOCKET,5X20 (Ref # 92154A)	92154-0210	2
DAMPER (Ref # 92160)	92160-1613	6
WASHER,NYLONE,5.3X11.5X0.5 (Ref # 92200)	92200-0006	8
WASHER,10.4X15.9X0.5 (Ref # 92200A)	92200-0157	6