

Cowling(Upper)

Let the Good Times Roll®



2015 Ninja 1000 ABS

PARTS LIST

Cowling(Upper)

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
CAP,MIRROR (Ref # 11065)	11065-0945	2
SHAFT (Ref # 13107)	13107-0241	1
LEVER,ADJUST (Ref # 13168)	13168-0211	1
COVER,METER,F.BLACK (Ref # 14092)	14092-0792-6Z	1
BRACKET-COMP (Ref # 23062)	23062-0136	1
STOPPER (Ref # 32085)	32085-0201	2
STAY,LH (Ref # 35063)	35063-0738	1
STAY,RH (Ref # 35063A)	35063-0739	1
STAY-COMP,LH (Ref # 39137)	39137-0064	1
STAY-COMP,RH (Ref # 39137A)	39137-0065	1
WINDSHIELD (Ref # 39154)	39154-0052	1
BRACKET-ASSY,WINDSHIELD (Ref # 39184)	39184-0026	1
COWLING,CNT,F.BLACK (Ref # 55028)	55028-0353-6Z	1
COWLING,UPP,M.S.BLACK (Ref # 55028E)	55028-0507-660	1
MIRROR-ASSY,LH (Ref # 56001)	56001-0259	1
MIRROR-ASSY,RH (Ref # 56001A)	56001-0260	1
NUT,FLANGED,6MM,BLACK (Ref # 92015)	92015-1233	4
NUT,WELL,5MM (Ref # 92015A)	92015-1757	12
SPRING (Ref # 92145)	92145-0805	2
BOLT,SOCKET,6MM (Ref # 92150)	92150-1154	2
COLLAR,10X20X3.75 (Ref # 92152)	92152-0913	4
COLLAR,5.6X8X7.8 (Ref # 92152A)	92152-1506	2
BOLT,SOCKET,8X35 (Ref # 92153)	92153-0419	2
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0026	2
BOLT,SOCKET,5X16 (Ref # 92154A)	92154-0209	6
BOLT,SOCKET,5X10 (Ref # 92154B)	92154-0211	2
BOLT,SOCKET,5X16 (Ref # 92154C)	92154-0287	4
BOLT,SOCKET,5X14 (Ref # 92154D)	92154-0427	2
BOLT,SOCKET,5X12 (Ref # 92154E)	92154-0503	2

2015 Ninja 1000 ABS

PARTS LIST

Cowling(Upper)

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,5X20 (Ref # 92154F)	92154-0829	4
DAMPER (Ref # 92161)	92161-0056	2
DAMPER,8.2X15X3 (Ref # 92161A)	92161-0998	2
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0238	1
WASHER,NYLON,5.3X11.5X0.5 (Ref # 92200)	92200-0006	12
WASHER,8.2X15X1 (Ref # 92200A)	92200-0742	4