

Handlebar

Let the Good Times Roll®

Exploded view diagram of a vehicle's front suspension and steering components. The diagram includes the following parts and labels:

- 14091**: Steering knuckle
- 92039**: Bolt
- 11053**: Bushing
- 11053A**: Bushing
- 46003**: Control arm
- 54012**: Steering knuckle
- 92161**: Bolt
- 54005**: Control arm
- 54017**: Control arm
- 54011**: Control arm
- 13042A**: Bushing
- 92026**: Bolt
- 92210**: Bushing
- 92200**: Bolt
- 13042**: Bushing
- 92172**: Bolt
- 13041**: Control arm
- 92171C**: Bolt
- 92171A**: Bolt
- 13070**: Control arm
- 13070A**: Control arm
- 92171B**: Bolt
- 92153**: Bolt
- 32085**: Bolt
- 92171**: Bolt

A **FRONT** arrow is located in the bottom left corner, indicating the vehicle's orientation.

2006 KFX400

PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,STEERING COVER,RH (Ref # 11053)	11053-S013	1
BRACKET,STEERING COVER,LH (Ref # 11053A)	11053-S014	1
BALANCER,HANDLEBAR (Ref # 13041)	13041-S003	2
WEIGHT (Ref # 13042)	13042-S003	2
WEIGHT,HANDLE BALANCER (Ref # 13042A)	13042-S004	2
GUIDE,CABLE (Ref # 13070)	13070-S011	1
GUIDE,PARKING CABLE (Ref # 13070A)	13070-S032	1
COVER,STEERING HEAD,BLACK/WHIT (Ref # 14091)	14091-S183-564	1
STOPPER,CLUTCH CABLE (Ref # 32085)	32085-S012	1
HANDLE (Ref # 46003)	46003-S013	1
CABLE-BRAKE (Ref # 54005)	54005-S015	1
CABLE-CLUTCH (Ref # 54011)	54011-S005	1
CABLE-THROTTLE (Ref # 54012)	54012-S018	1
CABLE-STARTER (Ref # 54017)	54017-S001	1
SPACER (Ref # 92026)	92026-S098	2
RIVET,BLACK (Ref # 92039)	92039-S005-506	2
BOLT (Ref # 92153)	92153-S011	2
DAMPER,STARTER CABLE (Ref # 92161)	92161-S086	1
CLAMP,L=125 (Ref # 92171)	92171-S014	3
CLAMP,CLUTCH CABLE (Ref # 92171A)	92171-S093	1
CLAMP,PARKING CABLE (Ref # 92171B)	92171-S094	1
CLAMP,BRAKE CABLE (Ref # 92171C)	92171-S165	1
SCREW,BALANCER (Ref # 92172)	92172-S172	2
WASHER (Ref # 92200)	92200-S132	2
NUT (Ref # 92210)	92210-S034	2