

Rear Suspension

Let the Good Times Roll®

This diagram illustrates the assembly of a vehicle chassis component, likely a rear suspension or steering knuckle. The main body is a large, curved metal casting (36014) with a mounting bracket (36014A) and a lower bracket (36014B). A shock absorber (45014) is shown being installed into the upper bracket. A long axle assembly (33032) with a wheel hub (92153A) is shown being inserted into the lower bracket. Various other components like bushings (92139, 12053, 92026), pins (92210), and screws (92172) are shown in their respective positions for assembly.

Key components and their labels:

- 92153: Small pin or bushing at the top of the shock absorber.
- 45014: Shock absorber assembly.
- 33032: Long axle assembly.
- 92153A: Wheel hub or bushing on the axle.
- 92210A: Pin or bushing on the upper bracket.
- 36014A: Upper mounting bracket.
- 36014: Main chassis casting.
- 92139: Bushing or pin on the lower bracket.
- 12053: Small pin or bushing.
- 92026: Small pin or bushing.
- 33001: Main chassis casting (alternative label for 36014).
- 92139: Bushing or pin on the lower bracket.
- 92210: Pin or bushing on the lower bracket.
- 36014B: Lower mounting bracket.
- 92172: Small screw or pin on the lower bracket.



2006 KFX50

PARTS LIST

Rear Suspension

ITEM NAME	PART NUMBER	QUANTITY
GUIDE-CHAIN (Ref # 12053)	12053-S013	1
ARM-COMP-SWING,BLACK (Ref # 33001)	33001-S005-503	1
SHAFT-SWING ARM (Ref # 33032)	33032-S002	1
CASE-CHAIN (Ref # 36014)	36014-S002	1
CASE-CHAIN (Ref # 36014A)	36014-S003	1
CASE-CHAIN (Ref # 36014B)	36014-S004	1
SHOCKABSORBER,L.GREEN (Ref # 45014)	45014-S021-535	1
SPACER (Ref # 92026)	92026-S063	1
BUSHING (Ref # 92139)	92139-S015	2
BOLT,10X37 (Ref # 92153)	92153-S033	1
BOLT,REAR SHOCK (Ref # 92153A)	92153-S204	1
SCREW,6X16 (Ref # 92172)	92172-S073	6
NUT (Ref # 92210)	92210-S007	1
NUT (Ref # 92210A)	92210-S030	1