

Rear Fender(s)

Let the Good Times Roll®

This diagram illustrates the assembly of a motorcycle seat, showing the main seat body, backrest, and various mounting hardware. The components are labeled with part numbers:

- Seat Body and Backrest:** 14091 (Seat Body), 14091A (Seat Body with Backrest), 16073 (Backrest Panel), 35023/A/B (Seat Cushion).
- Mounting Hardware:**
 - 92153A:** Screws for attaching the backrest to the seat body.
 - 92153B:** Screws for attaching the seat body to the frame.
 - 92152:** Washers used with the 92153 screws.
 - 92161:** Spacers used with the 92152 washers.
 - 92172:** Screws for attaching the seat body to the frame.
 - 92210:** Screws for attaching the seat body to the frame.
 - 92033:** Screws for attaching the seat body to the frame.
 - 92161A:** Washers used with the 92153A screws.
- Other Components:**
 - 55020:** A metal bracket or support.
 - 55020A:** A metal bracket or support.

A "FRONT" arrow is located in the bottom left corner of the diagram.

2008 KFX[®] 90

PARTS LIST

Rear Fender(s)

ITEM NAME	PART NUMBER	QUANTITY
COVER,SIDE,RH,BLACK (Ref # 14091)	14091-Y009-933	1
COVER,SIDE,LH,BLACK (Ref # 14091A)	14091-Y010-933	1
INSULATOR (Ref # 16073)	16073-Y003	1
FENDER-REAR,GREEN (Ref # 35023)	35023-Y001-930	1
FENDER-REAR,WHITE (Ref # 35023A)	35023-Y001-932	1
GUARD,SIDE,RH (Ref # 55020)	55020-Y002	1
GUARD,SIDE,LH (Ref # 55020A)	55020-Y003	1
RIVET (Ref # 92033)	92033-Y010	16
COLLAR (Ref # 92152)	92152-Y014	8
BOLT,6X16 (Ref # 92153)	92153-Y018	5
BOLT,6X20 (Ref # 92153A)	92153-Y019	8
BOLT,FLANGE,8X16 (Ref # 92153B)	92153-Y032	8
DAMPER (Ref # 92161)	92161-Y003	8
DAMPER (Ref # 92161A)	92161-Y005	2
SCREW,6X16 (Ref # 92172)	92172-Y004	4
NUT (Ref # 92210)	92210-Y031	4