

Cowling Lowers

Let the Good Times Roll®



2012 NINJA® ZX™-10R ABS

PARTS LIST

Cowling Lowers

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,FUSE BOX (Ref # 11056)	11056-0457	1
BRACKET (Ref # 11056A)	11056-0709	1
BRACKET (Ref # 11056B)	11056-0710	1
PAD,49X400X0.3 (Ref # 39156)	39156-0753	1
TRIM (Ref # 53044)	53044-0552	2
COWLING-ASSY,INNER,LH,F.BLACK (Ref # 55027)	55027-0060-6Z	1
COWLING-ASSY,INNER,RH,F.BLACK (Ref # 55027A)	55027-0061-6Z	1
COWLING,SIDE,UPP,LH,M.S.BLACK (Ref # 55028B)	55028-0333-660	1
COWLING,SIDE,UPP,RH,M.S.BLACK (Ref # 55028F)	55028-0334-660	1
COWLING,SIDE,FR,LH,F.BLACK (Ref # 55028H)	55028-0336-6Z	1
COWLING,SIDE,FR,RH,F.BLACK (Ref # 55028I)	55028-0337-6Z	1
COWLING,SIDE,LH,P.RED (Ref # 55028K)	55028-0338-234	1
COWLING,SIDE,LH,M.F.P.GRAY (Ref # 55028L)	55028-0338-33P	1
COWLING,SIDE,RH,P.RED (Ref # 55028P)	55028-0339-234	1
COWLING,SIDE,RH,M.F.P.GRAY (Ref # 55028Q)	55028-0339-33P	1
NUT,WELL,5MM (Ref # 92015)	92015-1757	6
RIVET,HOLE 8MM (Ref # 92039)	92039-0014	1
RIVET (Ref # 92039A)	92039-0068	5
DAMPER (Ref # 92075)	92075-1067	2
COLLAR,5.3X7.3X5.3 (Ref # 92152)	92152-0912	2
BOLT,SOCKET,6MM (Ref # 92153)	92153-0489	2
BOLT,SOCKET,5X16 (Ref # 92154)	92154-0209	8
DAMPER (Ref # 92160)	92160-1613	2
SCREW,TAPPING,5X10 (Ref # 92172)	92172-0262	13
WASHER,NYLONE,5.3X11.5X0.5 (Ref # 92200)	92200-0006	6
WASHER,10.4X15.9X0.5 (Ref # 92200A)	92200-0157	2