



# 2014 NINJA® 650 ABS

## PARTS LIST

### Cowling Lowers(FDS-FFF)

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,LWR,LH (Ref # 11056)	11056-0994	1
BRACKET,LWR,RH (Ref # 11056A)	11056-0995	1
BRACKET,FR COWLING,LH (Ref # 11056B)	11056-1214	1
BRACKET,FR COWLING,RH (Ref # 11056C)	11056-1215	1
BRACKET,PAD,RH (Ref # 11056D)	11056-1216	1
BRACKET,PAD,LH (Ref # 11056E)	11056-1545	1
PAD,10X25 (Ref # 39156)	39156-0721	8
PAD (Ref # 39156A)	39156-0796	1
PAD (Ref # 39156B)	39156-0797	1
PAD,152X20X10 (Ref # 39156C)	39156-0798	1
PAD,166X40X10 (Ref # 39156D)	39156-0799	1
PAD (Ref # 39156E)	39156-0860	1
PAD (Ref # 39156F)	39156-0861	1
PAD (Ref # 39156G)	39156-0871	2
COWLING,SIDE,LH,C.B.ORANGE (Ref # 55028)	55028-0370-15T	1
COWLING,SIDE,LH,M.M.GRAY (Ref # 55028B)	55028-0370-25X	1
COWLING,SIDE,LH,C.L.GREEN (Ref # 55028D)	55028-0370-35P	1
COWLING,SIDE,RH,C.B.ORANGE (Ref # 55028H)	55028-0371-15T	1
COWLING,SIDE,RH,M.M.GRAY (Ref # 55028J)	55028-0371-25X	1
COWLING,SIDE,RH,C.L.GREEN (Ref # 55028L)	55028-0371-35P	1
COWLING,FIN,LH,M.F.S.BLACK (Ref # 55028P)	55028-0372-739	1
COWLING,FIN,RH,M.F.S.BLACK (Ref # 55028Q)	55028-0373-739	1
COWLING,LWR,LH,M.F.S.BLACK (Ref # 55028R)	55028-0374-739	1
COWLING,LWR,RH,M.F.S.BLACK (Ref # 55028S)	55028-0375-739	1
COWLING,FR,LH (Ref # 55028T)	55028-0376	1
COWLING,FR,RH (Ref # 55028U)	55028-0377	1
RIVET,HOLE 8MM (Ref # 92039)	92039-0014	3
RIVET (Ref # 92039A)	92039-0068	6
RIVET (Ref # 92039B)	92039-0090	6

# 2014 NINJA® 650 ABS

## PARTS LIST

### Cowling Lowers(FDS-FFF)

ITEM NAME	PART NUMBER	QUANTITY
RIVET (Ref # 92039C)	92039-1283	3
GROMMET (Ref # 92071)	92071-0710	2
COLLAR (Ref # 92152)	92152-1359	4
BOLT,6X18 (Ref # 92153)	92153-0478	2
BOLT,FLANGED,6X14 (Ref # 92154)	92154-0777	4
BOLT,FLANGE BUTTON,6X18 (Ref # 92154A)	92154-0996	2
DAMPER,10X20X1 (Ref # 92161)	92161-1447	10
DAMPER,12X3 (Ref # 92161A)	92161-1448	2
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0742	14
WASHER,10.4X15.9X0.5 (Ref # 92200)	92200-0157	4
NUT (Ref # 92210)	92210-0571	4
BOLT-FLANGED,5X12 (Ref # 130)	130BA0512	4