

Suspension/Shock Absorber

Let the Good Times Roll®

Diagram illustrating the assembly of a vehicle chassis component, showing various parts and their reference numbers:

- 92154
- 92200
- 92055
- 92152
- 92173
- 92027
- 55020
- 92160A
- 92151
- 45014
- 92160
- 92049
- 92046
- 92049
- 42036
- 92153
- 92015
- Ref. Frame
- Ref. Swingarm
- FRONT

2024 Versys 650

PARTS LIST

Suspension/Shock Absorber



ITEM NAME	PART NUMBER	QUANTITY
SLEEVE,12.1X18X32 (Ref # 42036)	42036-0024	1
SHOCKABSORBER,BLACK (Ref # 45014)	45014-0722-10	1
GUARD (Ref # 55020)	55020-0977	1
NUT,LOCK,FLANGED,12MM (Ref # 92015)	92015-1433	1
COLLAR,6.8X10X11.5 (Ref # 92027)	92027-1210	2
BEARING-NEEDLE,SFYZM182417 (Ref # 92046)	92046-1272	1
SEAL-OIL (Ref # 92049)	92049-0133	2
RING-O,11.8X2.4 (Ref # 92055)	92055-0843	1
BOLT,SOCKET,6X35 (Ref # 92151)	92151-1390	2
COLLAR,12.1X16.8X4.4 (Ref # 92152)	92152-0811	1
BOLT,FLANGED,12X65 (Ref # 92153)	92153-1767	1
BOLT,FLANGED,12X55 (Ref # 92154)	92154-0289	1
DAMPER,SHOCKABSORBER (Ref # 92160)	92160-1161	1
DAMPER,10X20X12 (Ref # 92160A)	92160-1167	2
CLAMP,HOLDER CLIP (Ref # 92173)	92173-0868	1
WASHER,12.5X24X3.2 (Ref # 92200)	92200-0519	1