

Cowling Lowers

Let the Good Times Roll®



2009 Z1000 (European)

PARTS LIST

Cowling Lowers

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SHROUD,LH,LWR (Ref # 11054)	11054-0779	1
BRACKET,SHROUD,LH,UPP (Ref # 11054A)	11054-0797	1
BRACKET,SHROUD,RH,UPP (Ref # 11054B)	11054-0798	1
BRACKET,SHROUD,LH,UPP (Ref # 11054C)	11054-0848	1
BRACKET,SHROUD,RH,UPP (Ref # 11054D)	11054-0849	1
BRACKET,SHROUD,LH,LWR (Ref # 11054E)	11054-1498	1
BRACKET,SHROUD,RH,LWR (Ref # 11054F)	11054-1508	1
BRACKET,SHROUD,RH,LWR (Ref # 11055)	11055-0025	1
COVER,SHROUD,LH (Ref # 14091)	14091-0604	1
COVER,SHROUD,RH (Ref # 14091A)	14091-0605	1
SHROUD,LH,EBONY (Ref # 49125)	49125-0022-H8	1
SHROUD,LH,M.BLACK (Ref # 49125B)	49125-0022-17K	1
SHROUD,LH,A.SILVER (Ref # 49125C)	49125-0022-17M	1
SHROUD,RH,EBONY (Ref # 49125G)	49125-0023-H8	1
SHROUD,RH,M.BLACK (Ref # 49125I)	49125-0023-17K	1
SHROUD,RH,A.SILVER (Ref # 49125J)	49125-0023-17M	1
TRIM,L=100 (Ref # 53044)	53044-1200	4
WASHER,5.5X20X1.2 (Ref # 92022)	92022-1405	7
DAMPER (Ref # 92075)	92075-051	7
DAMPER (Ref # 92075A)	92075-1564	4
DAMPER (Ref # 92075B)	92075-1808	6
BOLT,SOCKET,6X14 (Ref # 92151)	92151-1654	8
BOLT,SOCKET,6X10 (Ref # 92153)	92153-0410	3
BOLT,SOCKET,6X16 (Ref # 92153A)	92153-1526	4
DAMPER (Ref # 92160)	92160-1613	1
CLAMP (Ref # 92170)	92170-1804	2
SCREW,TAPPING,5X10 (Ref # 92172)	92172-1061	7