

Cowling

Let the Good Times Roll®



2005 Z750S

PARTS LIST

Cowling

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED (Ref # 130)	130L0812	2
BOLT-FLANGED (Ref # 130A)	130L0830	2
BRACKET,MIRROR&METER (Ref # 11053)	11053-1431	1
BRACKET,UPP COWLING (Ref # 11053A)	11053-1432	1
WINDSHIELD (Ref # 39154)	39154-0001	1
PAD,UPP COWLING,CNT (Ref # 39156)	39156-0099	1
PAD,UPP COWLING,LH&RH (Ref # 39156A)	39156-0100	2
PAD,UPP COWLING,LH&RH (Ref # 39156B)	39156-0101	2
PAD,UPP COWLING,SIDE,LH,UPP (Ref # 39156C)	39156-0104	1
PAD,UPP COWLING,SIDE,RH,UPP (Ref # 39156D)	39156-0105	1
PAD,UPP COWLING,SIDE,LH,LWR (Ref # 39156E)	39156-0106	1
PAD,UPP COWLING,SIDE,RH,LWR (Ref # 39156F)	39156-0107	1
TRIM,L=75 (Ref # 53044)	53044-0009	2
COWLING,UPP,CNT,F.S.BLACK (Ref # 55028)	55028-0041-8J	1
COWLING,UPP,LH,C.P.BLUE (Ref # 55028A)	55028-0042-723	1
COWLING,UPP,RH,C.P.BLUE (Ref # 55028C)	55028-0043-723	1
COWLING,INNER,LH (Ref # 55028E)	55028-0044	1
COWLING,INNER,RH (Ref # 55028F)	55028-0045	1
COWLING,INNER,CNT (Ref # 55028G)	55028-0049	1
MIRROR-ASSY,LH (Ref # 56001)	56001-0037	1
MIRROR-ASSY,RH (Ref # 56001A)	56001-0038	1
SCREW,5X16 (Ref # 92009)	92009-1909	1
NUT,CAP,8MM,BLACK (Ref # 92015)	92015-1174	2
NUT,6MM (Ref # 92015A)	92015-1386	4
NUT,WELL,5MM (Ref # 92015B)	92015-1757	7
WASHER,NYLON,5.3X11.5X1.5 (Ref # 92022)	92022-1521	6
RIVET (Ref # 92039)	92039-0023	6
DAMPER (Ref # 92075)	92075-1011	2
DAMPER (Ref # 92075A)	92075-1690	4

2005 Z750S

PARTS LIST

Cowling

ITEM NAME	PART NUMBER	QUANTITY
BOLT,6X16 (Ref # 92151)	92151-1530	3
BOLT,SOCKET,6MM (Ref # 92153)	92153-0489	4
BOLT,SOCKET,5X16 (Ref # 92153A)	92153-1244	8
DAMPER,MIRROR (Ref # 92160)	92160-1089	4
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0175	6
WASHER,10.4X15.9X0.5 (Ref # 92200)	92200-0157	4
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	2
COWLING,UPP,LH,P.M.RED (Ref # 55028B)	55028-0042-724	1
COWLING,UPP,RH,P.M.RED (Ref # 55028D)	55028-0043-724	1