

Fenders

Let the Good Times Roll®

Diagram illustrating the assembly of a vehicle front end component, showing various parts and their assembly points. The diagram includes a "FRONT" arrow indicating orientation.

Key components and assembly points labeled:

- FRONT (Arrow)
- 92039A
- 35038B/C
- Ref. Front Box
- 92173
- 92161
- 92093
- 35038D/E
- Ref. Front Fender(s)
- 92039
- 92143
- 92009
- 35038A
- 35038

2025 RIDGE® HVAC CAMO

PARTS LIST

Fenders

ITEM NAME	PART NUMBER	QUANTITY
FENDER-FRONT,LWR,LH (Ref # 35038)	35038-0035	1
FENDER-FRONT,LWR,RH (Ref # 35038A)	35038-0036	1
FENDER-FRONT,UPP,LH,CAMOUFLAGE (Ref # 35038B)	35038-0039-72X	1
FENDER-FRONT,UPP,RH,CAMOUFLAGE (Ref # 35038D)	35038-0040-72X	1
SCREW,TAPPING,6X16 (Ref # 92009)	92009-1166	8
RIVET (Ref # 92039)	92039-0046	8
RIVET (Ref # 92039A)	92039-0776	18
SEAL,15X15X235 (Ref # 92093)	92093-0782	1
COLLAR (Ref # 92143)	92143-1057	8
DAMPER (Ref # 92161)	92161-1531	4
CLAMP (Ref # 92173)	92173-1423	4