

Oil Cooler

Let the Good Times Roll®

Exploded view diagram of a vehicle's front end components, including the hood, fender, and front suspension. The diagram shows various parts and their assembly points, with callouts for specific components and their quantities.

Parts and Callouts:

- 130**: Bolt
- 14037**: Hood
- 670**: Washer
- 92015**: Bolt
- 92027**: Bolt
- 92075**: Bolt
- 92210**: Bolt
- 27010**: Bolt
- 27010A**: Bolt
- 39067**: Bolt
- 51044**: Hose
- 59502**: Fan
- 35063**: Bolt
- 92153**: Bolt
- 11009**: Bolt
- 92001**: Bolt
- Ref. Crankcase**: Crankcase

Assembly Instructions:

- Install the hood (14037) onto the front of the vehicle.
- Install the fan (59502) onto the front of the vehicle.
- Install the hose (51044) onto the front of the vehicle.
- Install the crankcase (Ref. Crankcase) onto the front of the vehicle.
- Install the bolts (130, 670, 92015, 92027, 92075, 92210, 27010, 27010A, 39067, 35063, 92153, 11009, 92001) as shown in the diagram.

2009 Prairie® 360

PARTS LIST

Oil Cooler

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X25 (Ref # 130)	130BB0625	4
O RING,8MM (Ref # 670)	670D1508	2
GASKET,14X19.5X1.4 (Ref # 11009)	11009-1461	4
SCREEN,OIL COOLER (Ref # 14037)	14037-1313	1
SWITCH,OIL COOLER,RH (Ref # 27010)	27010-0005	1
SWITCH,OIL COOLER,LH (Ref # 27010A)	27010-0006	1
STAY (Ref # 35063)	35063-1212	4
COOLER-OIL (Ref # 39067)	39067-0002	1
TUBE-ASSY,L=1080 (Ref # 51044)	51044-1227	2
FAN-ASSY (Ref # 59502)	59502-1138	1
BOLT,14X28.5 (Ref # 92001)	92001-1930	2
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	4
COLLAR (Ref # 92027)	92027-1767	4
DAMPER (Ref # 92075)	92075-277	4
BOLT,6X22 (Ref # 92153)	92153-1087	4
NUT (Ref # 92210)	92210-1331	4