


1991 JET SKI® TS PARTS DIAGRAM

Electrical Equipment



F3181



1991 JET SKI® TS PARTS LIST

Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
HOLDER (Ref # 13091)	13091-3712	1
WIRE-LEAD,BATTERY-RELAY (Ref # 26011)	26011-3785	1
WIRE-LEAD,RELAY-STARTER (Ref # 26011A)	26011-3786	1
WIRE-LEAD,BATTERY-STARTER (Ref # 26011B)	26011-3787	1
BATTERY,YB16CL-B,12V 19AH (Ref # 26012)	26012-3716	1
BAND (Ref # 92072)	92072-3778	1