


## 1983 1100 LTD Shaft PARTS DIAGRAM

AIR CLEANER

E1130-0024



## 1983 1100 LTD Shaft PARTS LIST

### AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Canada) (Ref # 11010)	11010-1115	1
FILTER-ASSY-AIR (Ref # 11010A)	11010-1143	1
CAP,AIR FILTER (Ref # 11012)	11012-1167	1
ELEMENT,AIR CLNR (Ref # 11013)	11013-1037	1
BRACKET,AIR CLEANER (Ref # 11034)	32070-038	1
COVER,AIR FILTER,LH (Ref # 14025)	14025-1263	1
COVER,AIR FILTER,RH (Ref # 14025A)	14025-1264	1
DUCT,AIR FILTER,INTAK (Ref # 14073)	14073-1049	1
DUCT,AIR FILTER,OUTLE (Ref # 14073A)	14073-1055	1
VALVE ASSY,AIR SWITCH (Ref # 16126)	16126-1014	1
SILENCER (Ref # 39162)	39162-1003	1
FITTING,TUBE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12 (Ref # 92009)	92009-1105	1
CLAMP BREATHER PIPE (Ref # 92037)	92037-028	1
CLAMP-PIPE (Ref # 92037A)	92037-072	1
CLAMP (Ref # 92037B)	92037-1076	1
CLAMP,BREATHER TUBE (Ref # 92037C)	92037-213	1
TUBE,VACUUM,LONG (Ref # 92059)	92059-1162	2
TUBE,14X20X89 (Ref # 92059B)	92059-1155	1
TUBE,AIR FILTER BLEED (Ref # 92059C)	92059-1170	1
TUBE,14X20X340 (Ref # 92059D)	92059-1171	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1042	1
SPRING,COIL,BLACK (Ref # 92081)	92081-1457	1
BOLT-UPSET,6X12 (Ref # 110)	112G0612	1
SCREW PAN HEAD 6X12 (Ref # 220)	220B0612	1
WASHER PLAIN 6MM (Ref # 410)	410B0600	1
WASHER PLAIN 6MM (Ref # 411)	411B0600	1
WASHER SPRING 6MM (Ref # 461)	461F0600	1