


1986 Tecate® PARTS DIAGRAM

SWING ARM

F2141-0037



1986 Tecate® PARTS LIST

SWING ARM

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1355	1
CAP,SWING ARM (Ref # 11012A)	11012-1417	1
GUIDE-CHAIN,FR,UPP (Ref # 12053)	12053-1101	1
GUIDE-CHAIN (Ref # 12053A)	12053-1144	1
ARM-COMP-SWING (Ref # 33001)	33001-1265	1
SHAFT-SWING ARM (Ref # 33032)	33032-1112	1
ADJUSTER-CHAIN (Ref # 33040)	33040-4006	1
SLEEVE,SWING ARM,L=40 (Ref # 42036)	42036-1145	1
NUT,14MM (Ref # 92015)	92015-1407	1
BEARING-NEEDLE,TA2030 (Ref # 92046)	92046-1128	1
SCREW CNTSNK HD 6X10 (Ref # 221)	221B0610	1
NUT,8MM (Ref # 317)	317G0800	1
WASHER PLAIN 8MM (Ref # 411)	411B0800	1