


## 1986 Tecate® PARTS DIAGRAM

FRONT FORK

F237U-0203



## 1986 Tecate® PARTS LIST

### FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FORK DRAIN PLU (Ref # 11009)	11009-1553	1
GASKET FORK DRAIN PLG (Ref # 11009A)	44045-002	1
CAP,VALVE AIR (Ref # 11012)	11012-1391	1
VALVE (Ref # 16126)	16126-1147	1
FORK-FRONT (Ref # 44001)	44001-1602	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1237	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-1237	1
PIPE-FORK INNER (Ref # 44013)	44013-1235	1
PISTON-FORK,INNER PIP (Ref # 44018)	44018-1051	1
CYLINDER-FORK (Ref # 44022)	44022-1184	1
SPRING-FRONT FORK,UPP (Ref # 44026)	44026-1310	1
SPRING-FRONT FORK,LWR (Ref # 44026A)	44026-1311	1
GUIDE-FORK SPRING (Ref # 44028)	44028-1056	1
HOLDER-FORK UNDER (Ref # 44037)	44037-1190	1
HOLDER-FORK UPPER (Ref # 44039)	44039-1128	1
WASHER (Ref # 44043)	44043-052	1
BUSHING,FRONT FORK (Ref # 44065)	44065-1064	1
HOLDER-HANDLE,LWR (Ref # 46012)	46012-1124	1
BOOT,FORK (Ref # 49006)	49006-1182	1
LABEL,FRONT FORK (Ref # 56040)	56040-1120	1
BOLT,FORK TOP (Ref # 92001)	44041-065	1
BOLT,FORK DRAIN (Ref # 92002)	92002-1650	1
NUT,LOCK,10MM (Ref # 92015)	92019-021	1
WASHER,FORK OUTER TUB (Ref # 92022)	92022-1298	1
WASHER-HANDLEBAR FIT (Ref # 92022A)	92022-196	1
SPACER (Ref # 92026)	92026-1262	1
COLLAR,10.5X15.1X6 (Ref # 92027)	92027-1850	1
CIRCLIP (Ref # 92033)	92033-1036	1
SEAL-OIL,FORK (Ref # 92049)	92049-1245	1

## 1986 Tecate® PARTS LIST

### FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
RING-O (Ref # 92055)	92055-1321	1
BAND,BOOT (Ref # 92072)	92072-1077	1
BAND (Ref # 92072A)	92072-1166	1
BAND (Ref # 92072B)	92072-1204	1
BAND (Ref # 92072C)	92072-1206	1
DAMPER,HANDLE HOLDER (Ref # 92075)	92075-1725	1
BUSHING-RUBBER (Ref # 92092)	92092-1053	1
SEAL,FORK (Ref # 92093)	92093-1206	1
BOLT-UPSET-WP-SMALL (Ref # 184)	184G0840	1
SCREW PAN HEAD 4X8 (Ref # 220)	220B0408	1
SCREW PAN HEAD 4X16 (Ref # 220A)	220B0416	1
PIN COTTER 2.0X20 (Ref # 550)	550D2020	1