


## 1986 NINJA® ZX™-9R PARTS DIAGRAM

BALANCER/STARTER CLUTCH

E1323-0002



## 1986 NINJA® ZX™-9R PARTS LIST

### BALANCER/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
SPROCKET,GENERATOR (Ref # 12046)	12046-1068	1
BALANCER (Ref # 13041)	13041-1054	1
BOSS,SPROCKET (Ref # 13061)	13061-1111	1
BOSS,COUPLING (Ref # 13061A)	13061-1112	1
SHAFT (Ref # 13107)	13107-1108	1
LEVER (Ref # 13168)	13168-1236	1
CLUTCH-ASSY-ONEWAY (Ref # 13193)	13193-1052	1
SHAFT-COMP,BALANCER (Ref # 13234)	13234-1052	1
GEAR,BALANCER (Ref # 16085)	16085-1242	1
GEAR,ONEWAY CLUTCH (Ref # 16085A)	16085-1118	1
COUPLING (Ref # 42034)	42034-1055	1
COUPLING (Ref # 42034A)	42034-1056	1
WASHER,6X19.5X2 (Ref # 92022)	92022-1517	1
WASHER,8X22X3 (Ref # 92022A)	92022-1518	1
WASHER,16X26X2 (Ref # 92022B)	92022-1519	1
WASHER-THRUST (Ref # 92022C)	92022-225	1
SPACER,21.3X24.3X1.5 (Ref # 92026)	92026-1213	1
SPACER,BALANCER (Ref # 92026A)	92026-1214	1
SPACER,21.3X26X1 (Ref # 92026B)	92026-1223	1
PIN (Ref # 92043)	92043-087	1
BEARING,NEEDLE,K25302 (Ref # 92046)	92046-1022	1
BEARING-NEEDLE,K21X25 (Ref # 92046A)	92046-1105	1
BEARING-NEEDLE,K21X27 (Ref # 92046B)	92046-1108	1
BEARING-NEEDLE,RNA490 (Ref # 92046C)	92046-1109	1
SEAL-OIL,S192705 (Ref # 92049)	92049-1174	1
DAMPER,BALANCER (Ref # 92075)	92075-1590	1
DAMPER,COUPLING (Ref # 92075A)	92075-1790	1
SPRING (Ref # 92081)	92081-110	1
ROLLER (Ref # 92122)	92122-004	1

## 1986 NINJA® ZX™-9R PARTS LIST

BALANCER/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET,6X16 (Ref # 112)	112G0616	1
BOLT,8X20 (Ref # 115)	115G0820	1
BOLT,SOCKET,8X12 (Ref # 120)	120P0812	1
BOLT-FLANGED-SMALL (Ref # 132)	132J0616	1
BOLT-FLANGED-SMALL (Ref # 132A)	132J0620	1
NUT-HEX-FINE (Ref # 315)	315G1600	1
CIRCLIP,25M/M (Ref # 480)	480J2500	1
BEARING BALL #6203 (Ref # 601)	601A6203	1