


1988 JET SKI® JS300 PARTS DIAGRAM

Electrical Equipment



1988 JET SKI® JS300 PARTS LIST

Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
CAP (Ref # 11012)	11012-3004	1
CAP.,TERMINAL (Ref # 11012A)	59176-501	1
WIRE-LEAD,STARTER (Ref # 26011)	26011-3703	1
WIRE-LEAD,BATTERY(-) (Ref # 26011A)	26011-3708	1
WIRE-LEAD,BATTERY(+) (Ref # 26011B)	26011-3709	1
BATTERY,YB16CL-B,12V 19AH (Ref # 26012)	26012-3707	1