


1980 Invader 340 PARTS DIAGRAM

STEERING



Ref.
No.

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20
- 21
- 22
- 23
- 24
- 25
- 26
- 27

1980 Invader 340 PARTS LIST

STEERING

ITEM NAME	PART NUMBER	QUANTITY
HANDLE-BAR (Ref # 1)	46003-3502	1
CLAMP-WIRE (Ref # 2)	92037-3508	1
HOLDER-HANDLE (Ref # 3)	46012-3503	1
SCREW (Ref # 4)	92009-3510	1
GRIP-HANDLE BAR (Ref # 5)	46075-3501	1
BOLT (Ref # 6)	92001-3511	1
WASHER (Ref # 7)	92022-3528	1
HOLDER-HANDLE (Ref # 8)	46012-3502	1
BUSHING-STEERING (Ref # 9)	92028-3510	1
BLOCK-UPPER STEERING (Ref # 10)	39009-3501	1
POLE-STEERING (Ref # 11)	39100-3503	1
NUT (Ref # 12)	350BA1200	1
ROD-TIE-COMP (Ref # 13)	39111-3503	1
BOLT (Ref # 14)	119BA1222	1
ARM-STEERING LH (Ref # 15)	39006-3502	1
WASHER (Ref # 16)	92022-3511	1
ROD-TIE-END RH (Ref # 17)	39112-3504	1
BOLT (Ref # 18)	119BA1224	1
NUT (Ref # 19)	344BA1200	1
ROD-TIE (Ref # 20)	39111-3506	1
NUT (Ref # 21)	92015-3510	1
BOLT (Ref # 22)	119BA1228	1
ROD-TIE-END LH (Ref # 23)	39112-3505	1
ARM-STEERING RH (Ref # 24)	39006-3503	1
ROD-TIE-END LH FEMALE (Ref # 25)	39112-3506	1
STUD (Ref # 26)	92004-3502	1
BOLT (Ref # 27)	92001-3528	1