


1980 Invader 340 PARTS DIAGRAM

MAGNETO



Ref No
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

1980 Invader 340 PARTS LIST

MAGNETO

ITEM NAME	PART NUMBER	QUANTITY
GROMMET (Ref # 1)	92071-517	1
GROMMET (Ref # 2)	92071-529	1
COIL-IGNITION (Ref # 3)	21121-3004	1
SCREW PAN HEAD 6X25 (Ref # 4)	220B0625	1
WASHER SPRING 6MM (Ref # 5)	461F0600	1
WASHER,IGNITER (Ref # 6)	92022-3013	1
COLLAR-CLAMP (Ref # 7)	92027-291	1
CLAMP-IGNIT HARNESS (Ref # 8)	92037-3003	1
SCREW PAN HEAD 6X40 (Ref # 9)	220B0640	1
TERMINAL-ENG CONNECTR (Ref # 10)	21169-3001	1
CONNECTOR-HARNESS (Ref # 11)	59221-3001	1
SCREW PAN HEAD 4X10 (Ref # 12)	220B0410	1
WASHER SPRING 4MM (Ref # 13)	461F0400	2
WASHER (Ref # 14)	92022-558	1
IGNITER (Ref # 15)	21119-3021	1
GROMMET (Ref # 16)	92071-3501	1
SLEEVE-WIRE WRAP (Ref # 17)	42036-3506	1
STATOR ASSY (Ref # 18)	21003-3004	1
.COIL-PULSING (Ref # 19)	59026-3002	1
.SCREW 5X34 (Ref # 20)	92011-532	1
.COIL-LIGHTING (Ref # 21)	21047-3002	1
.CLAMP-STATOR WIRE (Ref # 22)	92037-518	1
.SCREW PAN HEAD 4X8 (Ref # 24)	220B0408	2
.COIL-EXCITING (Ref # 26)	21049-3001	1
.COLLAR-COIL (Ref # 27)	92027-521	1
.SCREW 5X38 (Ref # 28)	92009-3002	1
FLYWHEEL (Ref # 29)	21050-3002	1
SCREW PAN HEAD 5X20 (Ref # 30)	220B0520	1
WASHER SPRING 5MM (Ref # 31)	461F0500	1

1980 Invader 340 PARTS LIST

MAGNETO

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 32)	92022-544	1
SPARK PLUG BZ9EV (Ref # 33)	BZ9EV	1
CAP-SPARK PLUG (Ref # 35)	21130-3004	1
SPRING-SPARK PLUG CAP (Ref # 36)	92101-001	1