


1980 Invader LTD 4/6 PARTS DIAGRAM

LUBRICATION SYSTEM



SS440-B1

1980 Invader LTD 4/6 PARTS LIST

LUBRICATION SYSTEM

ITEM NAME	PART NUMBER	QUANTITY
BAND (Ref # 1)	92072-3502	1
FITTING-OIL TANK (Ref # 2)	92005-3505	1
TUBE-FUEL 1/4ID -100' (Ref # 3)	92059-3521	5
FITTING-FUEL PUMP (Ref # 4)	92005-3506	1
TUBE-FUEL 1/8ID -100' (Ref # 5)	92059-3519	3
PAD-OIL TANK (Ref # 6)	39156-3502	1
BAND (Ref # 7)	92072-3501	1
TUBE-FUEL 7/32ID-100' (Ref # 8)	92059-3520	2
PIPE-PICKUP-FUEL TANK (Ref # 9)	32032-3518	1
KEY-WOODRUFF (Ref # 11)	92038-3001	1
RING-O (Ref # 12)	92055-3005	1
PUMP-OIL (Ref # 13)	49042-3010	1
.PLATE-INLET (Ref # 14)	13169-3005	1
.SPRING,LEVER RETURN (Ref # 15)	92081-3007	1
.LEVER-CONTROL (Ref # 16)	13168-3001	1
WASHER-OIL PUMP (Ref # 17)	49091-3001	1
WASHER PLAIN 6MM (Ref # 18)	410B0600	1
BOLT-UPSET-WS,6X35 (Ref # 19)	180B0635	1
TUBE-CRANKCASE (Ref # 20)	92059-3003	1
CLAMP-OIL TUBE (Ref # 21)	92037-3002	1
VALVE-CHECK (Ref # 22)	16087-3001	1
GASKET-CHECK VALVE (Ref # 23)	92065-534	1
NOZZLE-CRANKCASE (Ref # 24)	92062-3001	1
NOZZLE-OIL (Ref # 25)	92062-503	1
TUBE-CYLINDER LH (Ref # 26)	92059-3002	1
TUBE-CYLINDER RH (Ref # 27)	92059-3001	1
TANK-OIL (Ref # 28)	52001-3501	1
CAP-OIL TANK (Ref # 29)	51049-3502	1