


1970 PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT ('70-'73)



1970 PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT ('70-'73)

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS MAIN (Ref # 1)	26001-049	1
WIRING HARNESS-MAIN (Ref # 1-1)	26001-068	1
WIRING HARNESS-MAIN (Ref # 1-1)	26001-074	1
COVER WIRING HARNESS (Ref # 2)	26009-003	1
WIRING HARNWSS REAR (Ref # 3)	26002-027	1
WIRING HARNESS-REAR (Ref # 3-1)	26002-029	1
WIRING HARNESS-REAR (Ref # 3-1)	26002-037	1
LEAD WIRE (Ref # 4)	26011-042	1
FUES ASSY (Ref # 5)	26004-008	1
FUSE 10A (Ref # 6)	26006-003	1
SWITCH BRAKE LAMP (Ref # 7)	27010-006	1
SWITCH-BRAKE LAMP (Ref # 7)	27010-020	2
SPRING BRAKE LAMP SW (Ref # 8)	27011-004	1
YUA BAT 6N2-2A-3 (Ref # 9)	K26012-019	1
YUA BAT 6N4-2A-5 (Ref # 9-1)	K26012-020	1
BAND RUBBER (Ref # 10)	92072-013	2
BAND,SHORT (Ref # 10-1)	92072-030	1
BAND RUBBER (Ref # 11)	92072-018	2
BAND,LONG (Ref # 11-1)	92072-032	1
HORN (Ref # 12)	27003-063	2
HORN (Ref # 12-1)	27003-056	2
BOLT,6X10 (Ref # 13)	112G0610	1
BOLT-SMALL-UPSET,8X16 (Ref # 13)	115G0816	1
WASHER SPRING 6MM (Ref # 14)	461F0600	1
WASHER SPRING 8MM (Ref # 14)	461F0800	1
WASHER PLAIN 8MM (Ref # 15)	411B0800	1
RELAY-TURN SIGNAL (Ref # 16)	27002-013	1