


1970 PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL ('74-'75)



1970 PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
BAR,L.H FOOTREST (Ref # 1)	34003-047	1
BAR,R.H FOOTREST (Ref # 2)	34003-048	1
STEP-ASSY,FR,LH (Ref # 3)	34027-1114	2
STEP-ASSY,FR,RH (Ref # 4)	34027-1115	2
PIN-FOOTREST BAR FIT (Ref # 5)	92043-080	1
WASHER PL 22.5X36X2.3 (Ref # 6)	92022-204	1
PIN COTTER 2.5X16 (Ref # 7)	550D2516	1
BOLT-UPSET,10X20 (Ref # 8)	112B1020	1
WASHER PLAIN 10MM (Ref # 9)	410B1000	2
NUT 10MM (Ref # 10)	315B1000	2
BAR SET-REAR FOOTREST (Ref # 11)	34030-001	1
RUBBER REAR FOOTREST (Ref # 12)	92076-008	1
WASHER SPRING 10MM (Ref # 14)	461F1000	1
NUT,10MM (Ref # 15)	314B1000	1
PEDAL,BRAKE (Ref # 16)	43001-055	1
PIN COTTER 3.0X30 (Ref # 17)	550D3030	1
WASHER BRAKE PEDAL (Ref # 18)	92022-085	1
PIN-BRAKE ROD FITTING (Ref # 19)	92043-064	1
ROD ASSY,BRAKE (Ref # 20)	43010-016	1
WASHER PLAIN 6MM (Ref # 21)	410B0600	1
PIN COTTER 2.0X15 (Ref # 22)	550D2015	1
SPRING,BRAKE ROD (Ref # 23)	43012-001	1
PIN BRAKE (Ref # 24)	92043-039	1
NUT-BRAKE ROD ADJUST (Ref # 25)	92015-042	1
STAND-SIDE (Ref # 26)	34024-028	1
SPRING MAIN STAND (Ref # 27)	34023-005	1
BOLT,10X28 (Ref # 28)	113G1028	1
SPRING BRAKE PEDAL (Ref # 30)	43005-007	1