



1974 KS125 PARTS DIAGRAM

SEAT/CHAIN COVER/CHAIN ('74-'75)



1974 KS125 PARTS LIST

SEAT/CHAIN COVER/CHAIN ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
SEAT ASSY,DUAL (Ref # 1)	53002-068	1
BRACKET,DUAL SEAT (Ref # 2)	53032-005	1
WASHER SPRING 6MM (Ref # 3)	461F0600	2
SCREW PAN HEAD 6X14 (Ref # 4)	220B0614	2
DAMPER RUBBER,SEAT (Ref # 5)	92075-219	1
DAMPER RUBBER,SEAT (Ref # 6)	92075-216	1
DAMPER RUBBER,BATTERY (Ref # 7)	92075-224	1
STOPPER,SEAT (Ref # 8)	53059-001	1
SPRING,HOOK (Ref # 9)	53012-013	1
PIN DUAL SEAT PIVOT (Ref # 10)	53011-001	1
HOOK,SEAT,L.H (Ref # 11)	53008-028	1
COTTER PIN (Ref # 12)	92041-003	1
HOOK,SEAT,R.H (Ref # 13)	53008-029	1
CASE-CHAIN,FR BLACK (Ref # 14)	36014-051-21	1
WASHER PLAIN (Ref # 15)	92022-024	1
DR CHAIN 428X118H (Ref # 18)	92057-030	1
JOINT ASSY DRIVE CHAIN (Ref # 19)	92058-005	1