



## 1972 S2 PARTS DIAGRAM

ENGINE COVERS



~ E/No. 11110

## 1972 S2 PARTS LIST

### ENGINE COVERS

ITEM NAME	PART NUMBER	QUANTITY
COVER-L.H ENGINE (Ref # 1)	14031-047	1
CAP,BREAKER POINT,BUF (Ref # 1-1)	14027-016-80	1
GASKET-POINT CAP (Ref # 2)	14050-005	1
COVER,R.H ENGINE,BUFF (Ref # 3)	14031-086-80	2
GASKET,L.H ENG COVER (Ref # 4)	14045-022	1
COVER,CHAIN CASE,BUFF (Ref # 5)	14026-022-80	2
SEAL-OIL (Ref # 6)	92049-1249	1
COVER,OIL PUMP,BUFF (Ref # 7)	14030-030-80	2
COVER,R.H,ENG. CLEAR (Ref # 8)	14032-1018	3
GASKET-R.H ENGINE COV (Ref # 9)	14046-019	1
HOLDER (Ref # 10)	14044-006	1
OIL SEAL (Ref # 11)	92054-004	1
BUSH (Ref # 12)	92028-075	1
"O" RING (Ref # 13)	92055-025	1
PIN,DOWEL (Ref # 14)	92042-035	1
SHAFT-TACHOMETER GEAR (Ref # 15)	13226-005	1
GEAR-TACHOMETER (Ref # 16)	13224-008	1
GEAR-OIL PUMP (Ref # 17)	16085-017	1
WASHER THRUST (Ref # 18)	92026-025	1
WASHER THRUST (Ref # 19)	92026-026	1
GROMMET-R.H ENG COVER (Ref # 20)	14038-030	1
OIL SEAL SB16244 (Ref # 21)	92049-002	1
HOLDER-TACHOMETER GR (Ref # 22)	14018-005	1
PIN-DOWEL (Ref # 23)	92042-007	1
CIRCLIP (Ref # 24)	92036-017	1
SCREW PAN HEAD 6X20 (Ref # 25)	220B0620	1
SCREW PAN HEAD 6X25 (Ref # 26)	220B0625	1
SCREW PAN HEAD 6X30 (Ref # 27)	220B0630	1
SCREW PAN HEAD 6X35 (Ref # 28)	220B0635	1

## 1972 S2 PARTS LIST

### ENGINE COVERS

ITEM NAME	PART NUMBER	QUANTITY
SCREW PAN HEAD 6X45 (Ref # 29)	220B0645	1
SCREW PAN HEAD 6X55 (Ref # 30)	220B0655	1
SCREW-PAN HEAD,6X90 (Ref # 31)	220B0690	1
SCREW PAN HEAD 6X100 (Ref # 32)	220B06100	1
PLUG-OIL FILLER (Ref # 33)	16115-017	1
"O" RING,20MM (Ref # 34)	670B2020	1