


1977 KZ400 Deluxe PARTS DIAGRAM

METERS/IGNITION SWITCH



1977 KZ400 Deluxe PARTS LIST

METERS/IGNITION SWITCH

ITEM NAME	PART NUMBER	QUANTITY
SWITCH ASSY IGNITION (Ref # 1)	27005-075	1
KEY SET,#751 (Ref # 2)	27008-064-51	1
KEY SET,#795 (Ref # 2)	27008-064-95	1
KEY,BLANK (Ref # 2)	27008-1013	1
NUT,IGNITION SW LOCK (Ref # 3)	27007-004	1
HOLDER,IGNITION SW (Ref # 4)	27019-004	1
SPEEDOMETER ASSY,MPH (Ref # 5)	25005-126	1
BULB 12V 3W (Ref # 6)	92069-018	1
DAMPER RUBBER (Ref # 7)	92075-268	1
COVER SPEEDOMETER (Ref # 8)	25012-020	1
COVER,SPEEDOMETER (Ref # 8)	25012-026	1
WASHER PLAIN 5MM (Ref # 9)	411B0500	1
WASHER SPRING 5MM (Ref # 10)	461F0500	1
NUT-CAP,5MM (Ref # 11)	322N0500	1
COVER INDICATOR LIGHT (Ref # 12)	25023-013	1
BRACKET METER (Ref # 13)	25008-037	1
COVER METER BRACKET (Ref # 14)	25024-005	1
SCREW-PAN-CRSOSS,4X12 (Ref # 15)	220B0412	1
WASHER SPRING 4MM (Ref # 16)	461F0400	1
DAMPER RUBBER (Ref # 17)	92075-257	1
WASHER,PLAIN,30MM (Ref # 18)	92022-264	1
NUT 6MM (Ref # 19)	311B0600	1
TACHOMETER ASSY (Ref # 20)	25016-027	1
BULB 12V 1.5W (Ref # 21)	92069-017	1
COVER TACHOMETER (Ref # 22)	25012-019	1
COVER,TACHOMETER (Ref # 22)	25012-027	1
SOCKET SPEEDO&TACHO (Ref # 23)	25011-047	1
COLLAR (Ref # 24)	92027-244	1