


1977 1000 LTD PARTS DIAGRAM

FRONT WHEEL/TIRE/HUB ('77-'78 B1/B2)



1977 1000 LTD PARTS LIST

FRONT WHEEL/TIRE/HUB ('77-'78 B1/B2)

ITEM NAME	PART NUMBER	QUANTITY
COLLAR,FRONT AXLE (Ref # 1)	41069-033	1
GEAR BOX ASSY (Ref # 2)	41078-008	1
PIN,SPRING (Ref # 3)	41082-001	1
WASHER THRST SPD PINI (Ref # 4)	41063-001	1
PINION,SPEEDOMETER (Ref # 5)	41060-017	1
BUSH,SPEEDMETER CABLE (Ref # 6)	41062-005	1
GEAR,SPEEDOMETER (Ref # 7)	41059-026	1
OIL SEAL,BJN30427-C3 (Ref # 8)	92049-1057	1
AXLE,FRONT (Ref # 9)	41068-049	1
BOLT (Ref # 10)	92001-158	1
WASHER,LOCK (Ref # 11)	92088-023	1
DUST COVER (Ref # 12)	41042-014	1
RECEIVER,GEAR (Ref # 13)	41064-013	1
BRG,BALL,#6203ZZC3 (Ref # 14)	601B6203ZZ	1
COLLAR,FR HUB BEARING (Ref # 15)	92027-1043	1
RING, SNAP,43.5M/M (Ref # 16)	92033-1040	1
OIL SEAL (Ref # 17)	654A254008	1
DUST COVER (Ref # 18)	41042-015	1
COLLAR,FRONT AXLE (Ref # 19)	41069-032	1
TIRE-FRONT (Ref # 20)	41021-071	1
TUBE 350/375/410-19 (Ref # 21)	41022-046	1
SOLID WHEEL ASSY,FRNT (Ref # 22)	41089-005	1
SOLID WHEEL ASSY,FRNT (Ref # 22)	41073-1040	1
BALANCER 5G (Ref # 23)	41075-005	1
BALANCER 10G (Ref # 24)	41075-006	1
BALANCER 30G (Ref # 25)	41075-008	2
BALANCER-WHEEL,10G (Ref # 27)	41075-1011	1
BALANCER-WHEEL,20G (Ref # 28)	41075-1012	1
BALANCER-WHEEL,30G (Ref # 29)	41075-1013	1