


2008 NINJA® ZX™-10R PARTS DIAGRAM

Fuel Injection

E1530



2008 NINJA® ZX™-10R PARTS LIST

Fuel Injection

| ITEM NAME | PART NUMBER | QUANTITY |
|--|-------------|----------|
| BOLT-SOCKET,5X22 (Ref # 120) | 120CB0522 | 1 |
| SENSOR,VEHICLE-DOWN (Ref # 21176) | 21176-0026 | 1 |
| SENSOR,AIR TEMPERATURE (Ref # 21176A) | 21176-0048 | 1 |
| SENSOR,PRESSURE (Ref # 21176B) | 21176-0058 | 1 |
| SENSOR,CAM (Ref # 21176C) | 21176-0101 | 1 |
| SENSOR,WATER TEMP (Ref # 21176D) | 21176-1120 | 1 |
| SCREW,TAPPING,5X16 (Ref # 92009) | 92009-1984 | 1 |
| GASKET,12X22X2 (Ref # 92065) | 92065-097 | 1 |
| DAMPER (Ref # 92075) | 92075-1912 | 1 |
| COLLAR (Ref # 92152) | 92152-0134 | 1 |
| BOLT-FLANGED,6X16 (Ref # 92153) | 92153-1584 | 1 |
| DAMPER (Ref # 92161) | 92161-0041 | 1 |
| DAMPER,ECU (Ref # 92161A) | 92161-0529 | 1 |
| NUT,FLANGED,5MM (Ref # 92210) | 92210-0007 | 1 |
| CONTROL UNIT-ELECTRONIC (Ref # 21175) | 21175-0240 | 1 |
| CONTROL UNIT-ELECTRONIC (Ref # 21175A) | 21175-0241 | 1 |