


2014 NINJA® 300 PARTS DIAGRAM

Turn Signals



2014 NINJA® 300 PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN-WP-CROS,4X8 (Ref # 224)	224AB0408	1
SOCKET-ASSY,FR,LH (Ref # 23008)	23008-0139	1
SOCKET-ASSY,FR,RH (Ref # 23008A)	23008-0144	1
LAMP-ASSY-SIGNAL,RR,LH (Ref # 23037)	23037-0247	1
LAMP-ASSY-SIGNAL,RR,RH (Ref # 23037A)	23037-0248	1
LAMP-SIGNAL,FR,LH (Ref # 23040)	23040-0107	1
LAMP-SIGNAL,FR,RH (Ref # 23040A)	23040-0108	1
LENS-SIGNAL LAMP,RR,LH (Ref # 23048)	23048-0014	1
LENS-SIGNAL LAMP,RR,RH (Ref # 23048A)	23048-0015	1
PAD,10X30X4 (Ref # 39156)	39156-0927	1
SCREW,TAPPING,5X14 (Ref # 92009)	92009-1197	1
BULB,12V 10W (Ref # 92069)	92069-0058	1
BULB,12V 10W (Ref # 92069A)	92069-0076	1
SCREW,2.9X22 (Ref # 92172)	92172-0395	1
WASHER,SIGNAL LAMP (Ref # 92200)	92200-0164	1
WASHER,SIGNAL LAMP (Ref # 92200A)	92200-0165	1