


2013 Jet Ski® Ultra® 300X PARTS DIAGRAM

Camshaft(s)/Tensioner

E1230



2013 Jet Ski® Ultra® 300X PARTS LIST

Camshaft(s)/Tensioner

ITEM NAME	PART NUMBER	QUANTITY
WASHER-PLAIN,6MM (Ref # 411)	411S0600	1
O RING,9MM (Ref # 670)	670D1509	1
TENSIONER-ASSY (Ref # 12048)	12048-0081	1
GUIDE-CHAIN,UPP (Ref # 12053)	12053-1432	1
GUIDE-CHAIN,RR (Ref # 12053A)	12053-3710	1
GUIDE-CHAIN,FR (Ref # 12053B)	12053-3711	1
SHAFT,CHAIN GUIDE (Ref # 13107)	13107-0157	1
CAMSHAFT-COMP,INTAKE (Ref # 49118)	49118-3717	1
CAMSHAFT-COMP,EXHAUST (Ref # 49118A)	49118-3719	1
RING-O,18.8X1.9 (Ref # 92055)	92055-086	1
CHAIN,98XRH2020-138L (Ref # 92057)	92057-3715	1
PLUG (Ref # 92066)	92066-3780	1
BUSHING,9X11X13.9 (Ref # 92139)	92139-0716	1
COLLAR (Ref # 92152)	92152-0981	1
BOLT,SOCKET,6X24.5 (Ref # 92153)	92153-1200	1
BOLT,6X25 (Ref # 92153A)	92153-3705	1
BOLT,6X28 (Ref # 92153B)	92153-3710	1