


2010 PARTS DIAGRAM

Crankcase

E1411



2010 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X8 (Ref # 132)	132BA0608	1
O RING,7MM (Ref # 670)	670D1507	1
PLATE (Ref # 13271)	13271-0334	1
PLATE (Ref # 13271A)	13271-0345	1
SET-CRANKCASE (Ref # 14001)	14001-0093	1
WASHER,6.2X11X1 (Ref # 92022)	92022-304	1
PIN,10X14 (Ref # 92043)	92043-1506	1
BEARING-BALL,B32-32-A-DUX8EC4 (Ref # 92045A)	92045-0031	1
BEARING-BALL,25X52X15 (Ref # 92045B)	92045-0035	1
BEARING-BALL,20X42X12 (Ref # 92045C)	92045-0036	1
BEARING-BALL,6202SH2C3 (Ref # 92045D)	92045-0037	1
BEARING-BALL,6904C3UR5 (Ref # 92045E)	92045-0038	1
BEARING-BALL,3TM-5X0391LUC3 (Ref # 92045F)	92045-0057	1
BEARING-BALL (Ref # 92045G)	92045-0062	1
BEARING-BALL (Ref # 92045H)	92045-0132	1
BEARING-BALL,6805JRZ (Ref # 92045I)	92045-1432	1
BEARING-NEEDLE,HK1210 (Ref # 92046)	92046-1010	1
BEARING-NEEDLE,HK1312 (Ref # 92046A)	92046-1148	1
BEARING-NEEDLE,7E-HKS33X38X8 (Ref # 92046B)	92046-1221	1
SEAL-OIL,TC 30 40 7 (Ref # 92049)	92049-0030	1
SEAL-OIL,12X16X3 (Ref # 92049A)	92049-0087	1
SEAL-OIL,TC4 8 18 7 (Ref # 92049B)	92049-0088	1
SEAL-OIL,TB13225.5 (Ref # 92051)	92051-005	1
NOZZLE,6X7 (Ref # 92062)	92062-0013	1
GASKET,10.5X16X1 (Ref # 92065)	92065-058	1
PLUG,DRAIN,10X22 (Ref # 92066)	92066-0038	1
SEAL,BLIND,LH CRANKCASE (Ref # 92093)	92093-0071	1
BOLT,6X50 (Ref # 92151)	92151-1545	1
BOLT,7X60 (Ref # 92153)	92153-0846	1

2010 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT,FLANGED,6X85 (Ref # 92153A)	92153-0934	1
BOLT,TORX,6X8.7 (Ref # 92153B)	92153-1669	1
CLAMP (Ref # 92171)	92171-0579	1
WASHER,6.3X13.5X1.0 (Ref # 92200)	92200-0171	1