


## 1987 Vulcan® 88 SE PARTS DIAGRAM

Handlebar

F2310-0418



## 1987 Vulcan® 88 SE PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
WEIGHT,HANDLE (Ref # 13042)	13042-1068	1
HANDLE (Ref # 46003)	46003-1243	1
HOLDER-HANDLE (Ref # 46012)	46012-1171	1
GRIP-ASSY,THROTTLE (Ref # 46019)	46019-1065	1
GRIP,LH (Ref # 46075)	46075-1074	1
HOUSING-ASSY-CONTROL,RH (Ref # 46091)	46091-1448	1
HOUSING-ASSY-CONTROL,LH (Ref # 46091A)	46091-1449	1
MIRROR-ASSY,LH (Ref # 56001)	56001-1303	1
MIRROR-ASSY,RH (Ref # 56001A)	56001-1304	1
SCREW,8X20 (Ref # 92009)	92009-1484	1
NUT,LOCK,FLANGED,10MM (Ref # 92015)	92015-1717	1
PLUG (Ref # 92066)	92066-1285	1
COLLAR,HANDLE HOLDER (Ref # 92143)	92143-1098	1
BOLT-SOCKET,10X25 (Ref # 120)	120P1025	1
SCREW-PAN-CROS,5X14 (Ref # 220)	220E0514	1