


1992 PARTS DIAGRAM

Generator



1992 PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
COVER-GENERATOR (Ref # 14031)	14031-1311	1
GENERATOR (Ref # 21001)	21001-1123	1
STATOR,GENERATOR (Ref # 21003)	21003-1162	1
ROTOR,GENERATOR (Ref # 21007)	21007-1152	1
BRUSH,CARBON (Ref # 21039)	21039-1058	1
SPRING-BRUSH (Ref # 21040)	21040-1054	1
RECTIFIER (Ref # 21061)	21061-1056	1
REGULATOR-VOLTAGE (Ref # 21066)	21066-1062	1
WIRE-LEAD,GENERATOR (Ref # 26011)	26011-1537	1
BRACKET-ASSY,FR (Ref # 39184)	39184-1063	1
BRACKET-ASSY,RR (Ref # 39184A)	39184-1064	1
COUPLING (Ref # 42034)	42034-1084	1
BOLT,8X45 (Ref # 92002)	92002-1658	1
SCREW (Ref # 92009)	92009-1451	1
SCREW (Ref # 92009A)	92009-1452	1
NUT (Ref # 92015)	92015-1624	1
WASHER,6X19.5X2 (Ref # 92022)	92022-1517	1
CLAMP,WIRING HARNESS (Ref # 92037)	92037-1539	1
BEARING-BALL (Ref # 92045)	92045-1181	1
BEARING-BALL (Ref # 92045A)	92045-1279	1
SEAL-OIL (Ref # 92049)	92049-1274	1
RING-O (Ref # 92055)	92055-1365	1
COLLAR (Ref # 92143)	92143-1054	1
SPRING,WASHER (Ref # 92144)	92144-1067	1
DAMPER,6.3X22X20 (Ref # 92160)	92160-1013	1
DAMPER (Ref # 92160A)	92160-1334	1
BOLT-UPSET (Ref # 112)	112G0616	1
BOLT-FLANGED-SMALL (Ref # 132)	132E0625	1