

2004 ZRX1200 PARTS LIST

Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 481)	481J5500	1
BEARING-BALL,#6006G (Ref # 601)	601B6006G	1
BEARING-BALL,#6304UUC3 (Ref # 601A)	601B6304UU	1
AXLE,RR (Ref # 41068)	41068-1429	1
WHEEL-ASSY,RR,BLACK (Ref # 41073)	41073-0017-R2	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1203	1
SLEEVE,RR HUB COUPLING,L=22 (Ref # 42036)	42036-1366	1
SPROCKET-HUB,42T (Ref # 42041)	42041-1387	1
STUD,10X19 (Ref # 92004)	92004-1275	1
NUT,FLANGED,10MM (Ref # 92015)	92015-1335	1
WASHER,23X32X2.3 (Ref # 92022)	92022-1618	1
COLLAR,RR AXLE,L=28 (Ref # 92027)	92027-1810	1
RING-SNAP,52MM (Ref # 92033)	92033-1043	1
RING-SNAP,RR AXLE (Ref # 92033A)	92033-1156	1
SEAL-OIL,28X52X5 (Ref # 92049)	92049-1061	1
SEAL-OIL,PJN40556 (Ref # 92049A)	92049-1263	1
CHAIN,DRIVE,DID50VA8X110L (Ref # 92057)	92057-0067	1
JOINT-CHAIN,DRIVE (Ref # 92058)	92058-0004	1
COLLAR,RR AXLE,RH,L=18 (Ref # 92143)	92143-1915	1
COLLAR,RR HUB (Ref # 92152)	92152-0129	1
COLLAR,RR AXLE,LH,L=19 (Ref # 92152A)	92152-1280	1
DAMPER,SHOCK,RR HUB (Ref # 92161)	92161-1069	1