


2006 NINJA® ZX™-12R PARTS DIAGRAM

Rear Hub



2006 NINJA® ZX™-12R PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 481)	481J5500	1
PIN-COTTER,4.0X40 (Ref # 550)	550D4040	1
BEARING-BALL,#6006G (Ref # 601)	601B6006G	1
BEARING-BALL (Ref # 601A)	601B6205UU	1
AXLE,RR (Ref # 41068)	41068-1416	1
WHEEL-ASSY,RR,C.GOLD (Ref # 41073)	41073-1681-457	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1203	1
SLEEVE,RR HUB,L=22 (Ref # 42036)	42036-1279	1
SPROCKET-HUB,46T (Ref # 42041)	42041-1523	1
STUD,10X19 (Ref # 92004)	92004-1275	1
NUT,FLANGED,10MM (Ref # 92015)	92015-1335	1
NUT,CASTLE,24MM (Ref # 92015A)	92015-1844	1
RING-SNAP,52MM (Ref # 92033)	92033-1043	1
SEAL-OIL,PJN40556 (Ref # 92049)	92049-1263	1
SEAL-OIL,RR HUB (Ref # 92049A)	92049-1375	1
CHAIN,DRIVE,DID50ZVM3X116L (Ref # 92057)	92057-1477	1
COLLAR,RR HUB,L=152.5 (Ref # 92152)	92152-1080	1
COLLAR,RR AXLE,LH,L=16.5 (Ref # 92152A)	92152-1181	1
COLLAR,RR AXLE,RH,L=16 (Ref # 92152B)	92152-1246	1
DAMPER,SHOCK,RR HUB (Ref # 92161)	92161-1286	1
WASHER,25.5X38X3.2 (Ref # 92200)	92200-1479	1