


2006 NINJA® ZX™-6RR PARTS DIAGRAM

Transmission



E1361

2006 NINJA® ZX™-6RR PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
BALL-STEEL,5/32" (Ref # 600)	600A0500	1
SHAFT-TRANSMISSION INPUT,16T (Ref # 13127)	13127-0033	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0018	1
SPROCKET-OUTPUT,15T (Ref # 13144)	13144-1324	1
GEAR,INPUT 2ND,18T (Ref # 13260)	13260-1987	1
GEAR,OUTPUT 2ND,37T (Ref # 13260A)	13260-1992	1
GEAR,OUTPUT 3RD,31T (Ref # 13260B)	13260-1993	1
GEAR,OUTPUT 4TH,33T (Ref # 13262)	13262-0044	1
GEAR,INPUT,3RD&4TH,18T&22T (Ref # 13262A)	13262-0143	1
GEAR,INPUT,5TH,21T (Ref # 13262B)	13262-0144	1
GEAR,OUTPUT 5TH,28T (Ref # 13262C)	13262-0150	1
GEAR,OUTPUT 6TH,27T (Ref # 13262D)	13262-0187	1
GEAR,INPUT 6TH,22T (Ref # 13262E)	13262-0188	1
GEAR,OUTPUT,LOW,39T (Ref # 13262F)	13262-0297	1
NUT,20MM (Ref # 92015)	92015-1963	1
BUSHING,INPUT 5TH GEAR (Ref # 92028)	92028-1735	1
BUSHING,INPUT TOP GEAR (Ref # 92028A)	92028-1736	1
BUSHING,OUTPUT,3RD&4TH (Ref # 92028B)	92028-1738	1
BUSHING,OUTPUT,2ND (Ref # 92028C)	92028-1739	1
RING-SNAP,20MM (Ref # 92033)	92033-015	1
RING-SNAP,24MM (Ref # 92033A)	92033-026	1
RING-SNAP,25.9X30.6X1.2 (Ref # 92033B)	92033-1037	1
BEARING-BALL,HR6205C3 (Ref # 92045)	92045-0009	1
BEARING-BALL,83993SH2-CS (Ref # 92045A)	92045-035	1
BEARING-NEEDLE,BN502053 (Ref # 92046)	92046-0014	1
BUSHING,27X34X18.6 (Ref # 92139)	92139-1090	1
COLLAR,23X32X15 (Ref # 92152)	92152-0280	1
WASHER (Ref # 92200)	92200-1065	1
WASHER,20.3X30X2.3 (Ref # 92200A)	92200-1238	1

2006 NINJA® ZX™-6RR PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER,25.2X31.0X1.5 (Ref # 92200B)	92200-1239	1
WASHER,28.5X34.0X1.5 (Ref # 92200C)	92200-1240	1
WASHER,20.3X33X1.0 (Ref # 92200D)	92200-1613	1