


2006 NINJA® ZX™-6RR PARTS DIAGRAM

Starter Motor



2006 NINJA® ZX™-6RR PARTS LIST

Starter Motor

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,8X12 (Ref # 120)	120P0812	1
BOLT-SOCKET,5X10 (Ref # 120A)	120S0510	1
WASHER-SPRING,5MM,BLACK (Ref # 461)	461K0500	1
BRACKET,STARTER (Ref # 11053)	11053-0224	1
SHAFT,7.8X12X26.5 (Ref # 13107)	13107-1176	1
PLATE (Ref # 13183)	13183-1460	1
CLUTCH-ASSY-ONEWAY (Ref # 13193)	13193-0001	1
GEAR-COMP,ONEWAY CLUTCH (Ref # 13216)	13216-0011	1
HOLDER,SWITCH (Ref # 13280)	13280-0109	1
STARTER-ELECTRIC (Ref # 21163)	21163-0006	1
FUSE,30A-G (Ref # 26006)	26006-1006	1
WIRE-LEAD (Ref # 26011)	26011-0065	1
SWITCH,MAGNETIC (Ref # 27010)	27010-0030	1
GEAR-SPUR,IDLE (Ref # 59051)	59051-1413	1
PIN (Ref # 92043)	92043-132	1
RING-O,STARTER (Ref # 92055)	92055-0013	1
RING-O,24.4X3.1 (Ref # 92055A)	92055-1262	1
RING-O (Ref # 92055B)	92055-1455	1
SPRING,COIL (Ref # 92081)	92081-159	1
ROLLER (Ref # 92122)	92122-006	1
SPRING,BRUSH (Ref # 92144)	92144-1423	1
BOLT (Ref # 92150)	92150-1305	1
BOLT,FLANGED-SMALL,6X25 (Ref # 92151)	92151-1930	1
BOLT (Ref # 92153)	92153-0405	1
WASHER,28.5X40.0X1.0 (Ref # 92200)	92200-0168	1
WASHER (Ref # 92200A)	92200-1019	1